

530 En/EnN Installation, operating, and maintenance manual

Contents

| | |
|--|-----------|
| 1 Certification | 3 |
| 1.1 Declaration of conformity | 4 |
| 1.2 Declaration of incorporation | 5 |
| 2 When you unpack your pump | 6 |
| 2.1 Unpacking your pump | 6 |
| 2.2 Packaging disposal | 6 |
| 2.3 Inspection | 6 |
| 2.4 Components supplied | 6 |
| 2.5 Storage | 6 |
| 3 Information for returning pumps | 7 |
| 4 Peristaltic pumps - an overview | 7 |
| 5 Warranty | 8 |
| 6 Safety notes | 9 |
| 7 Pump specifications | 12 |
| 7.1 Weights | 13 |
| 7.2 Pumphead options | 13 |
| 8 Good pump installation practice | 14 |
| 8.1 General recommendations | 14 |
| 8.2 Dos and don'ts | 15 |
| 9 Pump operation | 16 |
| 9.1 Keypad layout and key IDs | 16 |
| 9.2 Starting and stopping | 17 |
| 9.3 Using up and down keys | 17 |
| 9.4 Maximum speed | 17 |
| 9.5 Change rotation direction | 17 |
| 10 Connecting to a power supply | 18 |
| 10.1 Conductor colour coding | 19 |
| 10.2 Wiring the NEMA module - EtherNet/IP™ pumps | 19 |
| 10.3 M12 connector screen connection | 21 |
| 11 Start-up check list | 22 |
| 12 EtherNet/IP™ control wiring | 22 |
| 12.1 Features on the rear of the pump | 23 |
| 12.2 RJ45 connections | 24 |

| | |
|--|------------|
| 12.3 Control wiring | 24 |
| 12.4 N Module and F Module | 28 |
| 12.5 Input/output connectors | 31 |
| 12.6 EtherNet/IP™ pump external interface parameters | 33 |
| 12.7 Network topology | 34 |
| 13 Switching the pump on for the first time | 37 |
| 13.1 Selecting the display language | 37 |
| 13.2 First-time start-up defaults | 39 |
| 14 Switching the pump on in subsequent power cycles | 41 |
| 15 Main menu | 42 |
| 15.1 Security settings | 43 |
| 15.2 General settings | 54 |
| 15.3 Change mode | 67 |
| 15.4 Control settings | 68 |
| 15.5 Help | 69 |
| 16 Mode menu | 70 |
| 17 Manual | 71 |
| 17.1 Start | 71 |
| 17.2 Stop | 72 |
| 17.3 Increasing and decreasing flow rate | 72 |
| 18 Flow calibration | 74 |
| 18.1 Setting the flow calibration | 74 |
| 19 EtherNet/IP™ mode | 77 |
| 19.1 Configure EtherNet/IP™ settings | 77 |
| 19.2 EtherNet/IP™ mode | 81 |
| 19.3 Pump parameters | 81 |
| 19.4 EDS compatibility guide | 94 |
| 20 Dispense mode | 96 |
| 20.1 Create a new recipe or edit a recipe | 96 |
| 20.2 Create a new batch or edit a batch | 100 |
| 20.3 Set the active batch | 104 |
| 20.4 Start dispensing | 106 |
| 20.5 Dispense settings | 108 |
| 20.6 Dispense time delays diagram | 112 |
| 21 Dispense with EtherNet/IP™ control | 112 |
| 22 Sensors | 112 |
| 22.1 Sensor wiring | 113 |
| 22.2 Setting up the sensors | 114 |
| 22.3 Start up delay | 119 |
| 22.4 Generic sensors | 120 |

| | |
|--|------------|
| 22.5 Flow sensor reading | 134 |
| 23 Troubleshooting | 135 |
| 23.1 Error codes | 135 |
| 23.2 Technical support | 136 |
| 24 Drive maintenance | 137 |
| 25 Drive spares | 138 |
| 26 Pumphead replacement | 139 |
| 26.1 520R pumphead replacement | 139 |
| 27 Tube replacement | 140 |
| 27.1 Continuous tubing | 140 |
| 27.2 Tube elements | 141 |
| 28 Ordering information | 143 |
| 28.1 Pump part numbers | 143 |
| 28.2 Tubing and element part numbers | 144 |
| 28.3 Pumphead spares | 148 |
| 29 Performance data | 150 |
| 29.1 Performance curves | 150 |
| 30 Trademarks | 155 |
| 31 Disclaimers | 156 |
| 32 Publication history | 157 |
| 33 List of tables and figures | 158 |
| 33.1 Tables | 158 |
| 33.2 Figures | 159 |

Original instructions

The original instructions for this manual have been written in English. Other language versions of this manual are a translation of the original instructions

1 Certification

Certification documents follow on the next pages.

1.1 Declaration of conformity



Watson-Marlow Limited
Falmouth
Cornwall
TR11 4RU
England

EC Declaration of Conformity

- 530 Cased pumps (Models: S, SN, U, UN, Du, DuN, Bp, BpN, En, EnN, Pn, PnN)
630 Cased pumps (Models: S, SN, U, UN, Du, DuN, Bp, BpN, En, EnN, Pn, PnN)
730 Cased pumps (Models: SN, UN, DuN, BpN, EnN, PnN)
- Manufacturer:
Watson Marlow Ltd
Bickland Water Road
Falmouth
TR11 4RU
UK
- This declaration of conformity is issued under the sole responsibility of the manufacturer
- All models and versions of the 530, 630 and 730 series of cased peristaltic pump with all approved pump heads, tubing and accessories.
- The object of the declaration described above is in conformity with the relevant Union harmonisation legislation:
Machinery Directive 2006/42/EC
EMC Directive 2014/30/EC
ROHS Directive 2015/863
- Harmonised standards used:
BS EN61010-1:2010 third edition Safety requirements for electrical equipment for measurement, control, and laboratory use Part 1: General requirements
EN61326-1:2013 Electrical equipment for measurement, control and laboratory use – EMC requirements Part 1: General requirements
BS EN 60529:1992+A2:2013 Degrees of protection provided by enclosures (IP code)
- Intertek Testing and Certification Ltd, No: 3272281, performed compliance testing to UL 61010-1:2012 and CSA C22.2#61010-1-12:2012 and issued certification of compliance to these standards.

Signed for and behalf of:
Watson Marlow Ltd
Falmouth, December 2020

Simon Nicholson, Managing Director, Watson-Marlow Limited

1.2 Declaration of incorporation



Watson-Marlow Ltd
Falmouth
Cornwall
TR11 4RU
England

Declaration of Incorporation

In accordance with the Machinery Directive 2006/42/EC that if this unit is to be installed into a machine or is to be assembled with other machines for installations, it shall not be put into service until the relevant machinery has been declared in conformity.

We hereby declare that:

Peristaltic Pump

Series: 530, 630 and 730 cased pumps

the following harmonised standards have been applied and fulfilled for health and safety requirements:

Safety of Machinery – EN ISO 12100

Safety of Machinery – Electrical Equipment of Machines BS EN 60204-1

Quality Management System – ISO 9001

and the technical documentation is compiled in accordance with Annex VII(B) of the Directive.

We undertake to transmit, in response to a reasoned request by the appropriate national authorities, relevant information on the partly completed machinery identified above. The method of transmission shall be by mail or email.

The pump head is incomplete and must not be put into service until the machinery into which it is to be incorporated has been declared in conformity with the provisions of the Directive.

Person authorised to compile the technical documents:

Nancy Ashburn, Head of Design & Engineering, Watson-Marlow Ltd

Place and date of declaration: Watson-Marlow Ltd, 20.04.2020

Responsible person:

Simon Nicholson, Managing Director, Watson-Marlow Ltd

2 When you unpack your pump

2.1 Unpacking your pump

Unpack all parts carefully, retaining the packaging until you are sure all components are present and in good order. Check against the components supplied list, below.

2.2 Packaging disposal

Dispose of packaging materials safely, and in accordance with regulations in your area. The outer carton is made of corrugated cardboard and can be recycled.

2.3 Inspection

Check that all components are present. Inspect components for damage in transit. If anything is missing or damaged, contact your distributor immediately.

2.4 Components supplied

530 Components

- 530 pump drive unit, fitted with pumphead if specified as a pump
- The designated power cable (attached to the pump drive unit)
- A 530N module providing pump ingress protection to IP66, NEMA 4X, if a EnN.
- **Note:** the module is attached for transit, but must be removed to allow wiring up, voltage selection and fuse inspection and then re-affixed before the pump is operated.
- Product safety information booklet incorporating quick start manual

2.5 Storage

This product has an extended shelf life. However, care should be taken after storage to ensure that all parts function correctly. Please observe the storage recommendations and use-by dates which apply to tubing you may wish to bring into service after storage.

3 Information for returning pumps

Before returning products, they must be thoroughly cleaned/decontaminated. The declaration confirming this should be completed and returned to us in advance of the item being shipped.

You are required to complete and return a decontamination declaration stating all fluids that have been in contact with the equipment being returned to us.

On receipt of the declaration, we will issue a Returns Authorisation Number. We reserve the right to quarantine or refuse any equipment that is not displaying a Returns Authorisation Number.

Please complete a separate decontamination declaration for each product and use the correct form that denotes the location you wish to return the equipment to. A copy of the appropriate decontamination declaration can be downloaded from the Watson- Marlow website at www.wmftg.com/decon.

If you have any queries then please contact your local Watson-Marlow representative for further assistance at www.wmftg.com/contact.

4 Peristaltic pumps - an overview

Peristaltic pumps are the simplest possible pump, with no valves, seals or glands to clog or corrode. The fluid contacts only the bore of a tube, eliminating the risk of the pump contaminating the fluid, or the fluid contaminating the pump. Peristaltic pumps can operate dry without risk.

How they work

A compressible tube is squeezed between a roller and a track on an arc of a circle, creating a seal at the point of contact. As the roller advances along the tube, the seal also advances. After the roller has passed, the tube returns to its original shape, creating a partial vacuum which is filled by fluid drawn from the inlet port.

Before the roller reaches the end of the track, a second roller compresses the tube at the start of the track, isolating a packet of fluid between the compression points. As the first roller leaves the track, the second continues to advance, expelling the packet of fluid through the pump's discharge port. At the same time, a new partial vacuum is created behind the second roller into which more fluid is drawn from the inlet port.

Backflow and siphoning do not occur, and the pump effectively seals the tube when it is inactive. No valves are needed.

The principle may be demonstrated by squeezing a soft tube between thumb and finger and sliding it along: fluid is expelled from one end of the tube while more is drawn in at the other.

Animal digestive tracts function in a similar way.

Suitable applications

Peristaltic pumping is ideal for most fluids, including viscous, shear-sensitive, corrosive and abrasive fluids, and those containing suspended solids. They are especially useful for pumping operations where hygiene is important.

Peristaltic pumps operate on the positive displacement principle. They are particularly suitable for metering, dosing and dispensing applications. Pumps are easy to install, simple to operate and inexpensive to maintain.

5 Warranty

Watson-Marlow Limited ("Watson-Marlow") warrants this product to be free from defects in materials and workmanship for five years from the date of shipment, under normal use and service.

Watson-Marlow's sole responsibility and the customer's exclusive remedy for any claim arising out of the purchase of any product from Watson-Marlow is, at Watson-Marlow's option: repair, replacement or credit, where applicable.

Unless otherwise agreed in writing, the foregoing warranty is limited to the country in which the product is sold.

No employee, agent or representative of Watson-Marlow has the authority to bind Watson-Marlow to any warranty other than the foregoing unless in writing and signed by a director of Watson-Marlow. Watson-Marlow makes no warranty of the fitness of its products for a particular purpose.

In no event:

- i. shall the cost of the customer's exclusive remedy exceed the purchase price of the product;
- ii. shall Watson-Marlow be liable for any special, indirect, incidental, consequential, or exemplary damages, however arising, even if Watson-Marlow has been advised of the possibility of such damages.

Watson-Marlow shall not be liable for any loss, damage, or expense directly or indirectly related to or arising out of the use of its products, including damage or injury caused to other products, machinery, buildings, or property. Watson-Marlow shall not be liable for consequential damages, including without limitation, lost profits, loss of time, inconvenience, loss of product pumped, and loss of production.

This warranty does not obligate Watson-Marlow to bear any costs of removal, installation, transportation, or other charges which may arise in connection with a warranty claim.

Watson-Marlow shall not be responsible for shipping damage of returned items.

Conditions

- Products must be returned by pre-arrangement to Watson-Marlow, or a Watson-Marlow approved service centre.
- All repairs or modifications must have been made by Watson-Marlow Limited, or a Watson-Marlow approved service centre or with the express permission in writing of Watson-Marlow, signed by a manager or director of Watson-Marlow.
- Any remote control or system connections must be made in accordance to Watson-Marlow recommendations.
- All EtherNet/IP™ systems must be installed or certified by a suitably trained installation engineer.

Exceptions

- Consumable items including tubing and pumping elements are excluded.
- Pumphead rollers are excluded.
- Repairs or service necessitated by normal wear and tear or by lack of reasonable and proper maintenance are excluded.
- Products which, in the judgement of Watson-Marlow, have been abused, misused, or subject to malicious or accidental damage or neglect are excluded.
- Failure caused by electrical surge is excluded.
- Failure caused by incorrect or sub-standard system wiring is excluded.
- Damage by chemical attack is excluded.
- Ancillaries such as leak detectors are excluded.
- Failure caused by UV light or direct sunlight.
- All ReNu pumpheads are excluded
- Any attempt to disassemble a Watson-Marlow product will invalidate the product warranty.

Watson-Marlow reserves the right to amend these terms and conditions at any time.

6 Safety notes

This safety information should be used in conjunction with the rest of this operating manual.

In the interests of safety, this pump and pumphead should only be used by competent, suitably trained personnel after they have read and understood the manual and considered any hazard involved. If the pump is used in a manner not specified by Watson-Marlow Limited, the protection provided by the pump may be impaired. Any person who is involved in the installation or maintenance of this equipment should be fully competent to carry out the work. This person should also be familiar with all relevant health and safety protocols, regulations and guidance.



This symbol, used on the pump and in the manual, means: An appropriate safety instruction should be followed or caution to a potential hazard exists.



This symbol, used on the pump and in the manual, means: Do not allow fingers to contact moving parts.



This symbol, used on the pump and in the manual, means: Caution, hot surface.



This symbol, used on the pump and in the manual, means: Caution, risk of electric shock.



This symbol, used on the pump and in the manual, means: Personal Protective Equipment (PPE) must be worn.



This symbol, used on the pump and in the manual, means: Recycle this product under the terms of the EU Waste Electrical and Electronic Equipment (WEEE) Directive.



Within the 630 and 730 pumps there are thermal fuses which self-reset; if they trip, error code "Err17 Under Voltage" is displayed.



Fundamental work with regard to lifting, transportation, installation, starting-up, maintenance and repair should be performed by qualified personnel only. The unit must be isolated from mains power while work is being carried out. The motor must be secured against accidental start-up.



Some pumps weigh more than 18kg (the exact weight depends on the model and pumphead - see on the pump). Lifting should be performed according to standard Health and Safety guidelines. Finger recesses are built into the sides of the lower shell for convenience in lifting; in addition, the pump can conveniently be lifted by grasping the pumphead and (where fitted) the N Module at the rear of the pump.



There is a user-replaceable fuse located at the rear of the pump. Some country specific mains plugs contain an additional replaceable fuse. Fuses must be replaced with parts with the same rating.



There are no user-serviceable fuses or parts inside this pump.
Note - the mains power supply cable is supplied hardwired into the pump and is not customer replaceable.
Observe voltage selector switch setting for your region



IP66 pumps are supplied with a mains plug. The gland at the NEMA Module end of the cable is IP66 rated. The mains plug at the opposite end of the cable is NOT IP66 rated. It is the user's responsibility to ensure that the connection to the mains supply is IP66 rated.

This pump must be used only for its intended purpose.

The pump must be accessible at all times to facilitate operation and maintenance. Access points must not be obstructed or blocked. Do not fit any devices to the drive unit other than those tested and approved by Watson-Marlow. Doing so could lead to injury to persons or damage to property for which no liability can be accepted.

The pump's main plug is the disconnecting device (for isolating the motor drive from the mains supply in an emergency). Do not position the pump so that it is difficult to disconnect the mains plug.



If hazardous fluids are to be pumped, safety procedures specific to the particular fluid and application must be put in place to protect against injury to persons.



This product does not comply with the ATEX directive and must not be used in explosive atmospheres.



Ensure the chemicals to be pumped are compatible with the pumphead, lubricant (where applicable), tubing, pipework and fittings to be used with the pump. Please refer to the chemical compatibility guide which can be found at: www.wmftg.com/chemical. If you need to use the pump with any other chemical please contact Watson-Marlow to confirm compatibility.



If the Auto Restart feature is enabled it may cause the pump to start as soon as power is turned on.

Auto Restart only affects operation of manual mode and EtherNet/IP™ mode.

If Auto Restart is enabled the "!" Symbol is shown on the screen to warn users that the pump may operate without any manual intervention (pump resumes with previous settings).

Do not use Auto Restart for more than:

- 1 mains power start per 3 minutes

We recommend remote control where a high number of starts is required.



If the pump is configured to Dispense or EtherNet/IP™ mode it will respond to remote commands at any time including immediately after power on. The pump may operate without any manual intervention (e.g. a remote setpoint could start the pump with no key press required).



There are moving parts inside the pumphead. Before opening the tool-unlockable guard or tool-unlockable track, ensure that the following safety directions are followed:



1. Ensure the pump is isolated from the mains power.

2. Ensure that there is no pressure in the pipeline.



3. If a tube failure has occurred, ensure that any fluid in the pumphead has been allowed to drain to a suitable vessel, container or drain.

4. Ensure that appropriate Personal Protective Equipment (PPE) is worn.



Primary operator protection from rotating parts of the pump is provided by the pumphead safeguard. Note that safeguards differ, depending on the type of pumphead. See the pumphead section of the manual.

7 Pump specifications

Table 1 - Specification ratings

| | |
|---|---|
| Operating temperature | 5 °C to 40 °C (41 °F to 104 °F) |
| Storage temperature | 530: -40 °C to 70 °C (-40 °F to 158 °F) |
| Humidity (non-condensing) | 80 % up to 31 °C (88 °F) decreasing linearly to 50 % at 40 °C (104 °F) |
| Maximum altitude | 2000 m (6560 ft) |
| Power Rating | 530: 135 VA |
| Supply voltage | 100-120 V/200-240 V 50/60 Hz 1 pH (Subject to regional cord sets and supply) |
| Maximum voltage fluctuation | +/-10 % of nominal voltage. A well regulated electrical mains supply is required along with cable connections conforming to the best practice of noise immunity. |
| Full load current | 530: <0.6 A @ 230 V; <1.25 A @ 115 V |
| Fuse rating | T2.5AH250V (5x20 mm) |
| Installation category (overvoltage category) | II |
| Pollution degree | 2 |
| IP | 530: IP31 to BS EN 60529, if supplied with N module then IP66 to BS EN 60529. Meets the requirements of NEMA 4X to NEMA 250 * (indoor use - protect from prolonged UV exposure) |
| dB rating | |
|  | 530: < 70 dB (A) @ 1 m |
| Control ratio | 530: 0.1-220 rpm (2200:1) |
| Maximum speed | 530: 220 rpm |

7.1 Weights

Table 2 - Weights

| 530 | Drive only | | + 520R, 520R2 | | + 520REL, 520REM, 520REH, 520RET | | + 505L | |
|------|------------|-------|---------------|-------|----------------------------------|-------|--------|-------|
| | kg | lb oz | kg | lb oz | kg | lb oz | kg | lb oz |
| IP31 | 9.7 | 21 6 | 10.6 | 23 5 | 10.5 | 23 3 | 12.2 | 26 14 |
| IP66 | 10.6 | 23 5 | 11.5 | 25 5 | 11.4 | 25 2 | 13.1 | 28 13 |



Some pumps weigh more than 18 kg (the exact weight depends on the model and pumphead - see on the pump). Lifting should be performed according to standard Health and Safety guidelines. Finger recesses are built into the sides of the lower shell for convenience in lifting; in addition, the pump can conveniently be lifted by grasping the pumphead and (where fitted) the module at the rear of the pump.

7.2 Pumphead options

Figure 1 - 530 pump range

520R, 520R2, 520REH, 520REL, 520REM, 520RET, 505L, 505CA, 313, 314, 314MC and 318MC.



8 Good pump installation practice

8.1 General recommendations

It is recommended that the pump is sited on a flat, horizontal, rigid surface, free from excessive vibration, to ensure the correct lubrication of the gearbox and correct pumphead operation. Allow a free flow of air around the pump to ensure that heat can be dissipated. Ensure that the ambient temperature around the pump does not exceed the recommended maximum operating temperature. The STOP key on pumps supplied with a keypad will always stop the pump. However, it is recommended that a suitable local emergency stop device is fitted into the mains supply to the pump. Do not stack the pumps more than the recommended maximum number. When the pumps are stacked, ensure that the ambient temperature around all the pumps in the stack does not exceed the recommended maximum operating temperature.



Figure 2 - Pump stacking

The pump may be set up so that the direction of rotor rotation is clockwise or counter-clockwise, whichever is required.

Please note, however, that for some pumpheads the tube life will be greater if the rotor rotates clockwise; and that performance against pressure will be maximised if the rotor rotates counter-clockwise. To achieve pressure in some pumpheads the pump must rotate counter-clockwise.




Figure 3 - Rotor direction

Peristaltic pumps are self-priming and self-sealing against backflow. No valves are required in inlet or discharge line, except those specified as below.



Users must fit a non-return valve between the pump and the discharge pipework to avoid the sudden release of pressurised fluid in the event of a pumphead or tube failure. This shall be fitted immediately after the discharge of the pump.

Valves in the process flow must be opened before the pump operates. Users are advised to fit a pressure relief device between the pump and any valve on the discharge side of the pump to protect against damage caused by accidental operation with the discharge valve closed.

8.2 Dos and don'ts

- Do not build a pump into a tight location without adequate airflow around the pump.
- Do keep delivery and suction tubes as short and direct as possible - though ideally not shorter than one metre - and follow the straightest route. Use bends of large radius: at least four times the tubing diameter. Ensure that connecting pipework and fittings are suitably rated to handle the predicted pipeline pressure. Avoid pipe reducers and lengths of smaller bore tubing than the pumphead section, particularly in pipelines on the suction side. Any valves in the pipeline must not restrict the flow. Any valves in the flow line must be open when the pump is running.
- Do ensure that on longer tube runs at least one metre of smooth bore, flexible tubing is connected to the inlet and discharge port of the pumphead to help to minimise impulse losses and pulsation in the pipeline. This is especially important with viscous fluids and when connecting to rigid pipework.
- Do use suction and delivery pipes equal to or larger than the tubing diameter bore. When pumping viscous fluids use pipe runs with a bore several times larger than the pump tube.
- Do site the pump at or just below the level of the fluid to be pumped if possible. This will ensure flooded suction and maximum pumping efficiency.
- Do run at slow speed when pumping viscous fluids. Flooded suction will enhance pumping performance, particularly for materials of a viscous nature.
- Do recalibrate after changing tubing, fluid or any connecting pipework. It is also recommended that the pump is recalibrated periodically to maintain accuracy.
- Do not pump any chemical not compatible with the tube or pumphead.
- Do not run the pump with no tube or element fitted to the pumphead.
- Do not strap the control and mains cables together.
- Do ensure if your product has an N module, that the module is fitted with the seals intact and properly located. Ensure that the holes for the cable glands are properly sealed to maintain the IP/NEMA rating.

Tube selection: The chemical compatibility guide published on the Watson Marlow website is for guidance. If in any doubt about the compatibility of a tube material and the duty fluid, request a Watson-Marlow tube sample card for immersion trials.

When using Marprene or Bioprene continuous tubing, do re-tension the tube after the first 30 minutes of running.

9 Pump operation

9.1 Keypad layout and key IDs




Figure 4 - Keypad layout and key IDs

HOME key

When the **HOME** key is pressed it will return the user to the last known operating mode. If modifying pump settings when the **HOME** key is pressed, it will disregard any setting changes and return you to the last known operating mode.

FUNCTION keys

FUNCTION keys, when pressed, will perform the function displayed on the screen directly above the relevant function key.

^ and v keys

These keys are used to change the programmable values within the pump. These keys are also used to move the selection bar up and down in the menus.

MODE key

To change modes or mode settings, press the **MODE** key. The **MODE** key can be pressed at any time to enter the mode menu. If modifying pump settings when the **MODE** key is pressed, it will disregard any setting changes and return you to the **MODE** menu.

9.2 Starting and stopping




Figure 5 - Starting and stopping

9.3 Using up and down keys




Figure 6 - Using up and down keys

9.4 Maximum speed



Figure 7 - Maximum speed

9.5 Change rotation direction




Figure 8 - Change rotation direction

10 Connecting to a power supply

A well regulated electrical mains supply is required along with cable connections conforming to the best practice of noise immunity. It is not recommended to site these drives alongside electrical devices that may generate mains-borne noise, for example 3-phase contactors and inductive heaters.



Set the voltage selector to 115 V for 100-120 V 50/60 Hz supplies or 230 V for 200-240 V 50/60 Hz supplies. Always check the voltage selector switch before connecting to the mains supply or the pump will be damaged.

~100-120V



~200-240V



Make suitable connection to an earthed single-phase mains electricity supply.



If the pump type is one with an N Module, the voltage selector is not visible while the module is in place. It is mounted in the switch plate at the rear of the pump, protected from water by the N Module. The module must be removed to allow access to the switch plate. Do not switch the pump on unless you have checked that it is set to suit your power supply by removing the module and inspecting the switch and then refitting the module.

1.



3.



2.



4.



Figure 9 - Voltage selector



We recommend using a commercially available supply voltage surge and/or noise suppression where there is excessive electrical noise.



Ensure that all power supply cables are adequately rated for the equipment. Only use with supplied power cable.



The pump must be positioned so that the disconnection device is easily accessible when the equipment is in use. The pump's power input plug is the disconnecting device (for isolating the motor drive from the power supply in an emergency).



IP66 pumps are supplied with a mains plug. The gland at the NEMA Module end of the cable is IP66 rated. The mains plug at the opposite end of the cable is NOT IP66 rated. It is your responsibility to ensure that the connection to the mains supply is IP66 rated.

10.1 Conductor colour coding

Table 3 - Conductor colour coding

| Conductor type | European colour | North American colour |
|----------------|-----------------|-----------------------|
| Line | Brown | Black |
| Neutral | Blue | White |
| Ground | Green/Yellow | Green |

10.2 Wiring the NEMA module - EtherNet/IP™ pumps

The NEMA 4X modules fitted to 530, 630 and 730 EnN cased pumps have two pairs of wiring ports. Two M16 ports are provided, together with glands to seal circular cross-section cables ranging in diameter from 4 mm to 10 mm (5/32 in. to 13/32 in.) Ethernet connection is via the two M12 connectors mounted to the rear of the NEMA module.

Figure 10 - Earth screening of control cables on EtherNet/IP™ NEMA module



Control cable earth screening connected to Earth terminal (J6) on adapter PCB when plastic cable gland is used.

Figure 10 - Earth screening of control cables on EtherNet/IP™ NEMA module

②



No additional control cable earth screening required when EMC gland is used.



NEMA module with conductive mounting kit (available as an option on En pumps for EtherNet/IP™ network cables if required).

10.3 M12 connector screen connection

Figure 11 - M12 connector screen connection

EtherNet/IP™ models



1. By default the body and cable screen of the M12 Ethernet connectors are insulated from the metal body of the NEMA module and mains ground. This is in accordance to The EtherNet/IP™ specification for use in industrial automation systems using EtherNet/IP™.
2. If there is a requirement to connect the M12 body and cable screen (A) to Mains earth for EMC or Ethernet TCP reasons then the default plastic M12 mounting collar (MN2934T) can be replaced by a stainless steel version (MN2935T). Ensure the M12 O-ring and sealing washer are seated correctly to maintain IP66 sealing.

11 Start-up check list

Note: See also "Tube replacement " on page 140.

- Ensure that proper connections are achieved between the pump and suction and discharge piping.
- Ensure proper connection has been made to a suitable power supply.
- Ensure that the recommendations in the section "Good pump installation practice" on page 14 are followed.

12 EtherNet/IP™ control wiring




Never apply mains power to the D-connectors. Apply the correct signals to the pins shown. Limit signals to the maximum values shown. Do not apply voltage across other pins. Permanent damage, not covered by warranty, may result.



Keep 4-20 mA and low voltage signals separate from mains power. Use separate glanded input cables. Following best EMC practice and use of shielded glands is recommended.

12.1 Features on the rear of the pump



| | |
|---|--|
| 1 | RJ45 connection 1 |
| 2 | RJ45 connection 2 |
| 3 | Standard - 9 way D - Sensor connector (Female) |
| 4 | USB (Type A) port for service use only |
| 5 | Voltage selector switch |
| 6 | On/Off switch |
| 7 | Mains power cable |
| 8 | Customer replaceable fuse |

12.2 RJ45 connections

Connect an RJ45 (CAT5 or above, shielded recommended) network cable from the PC to the pump connection port 1 or 2.




Figure 12 - RJ45 connections

| LED 1 | LED 2 | Indication |
|-------|-------|--|
| Low | Low | Off |
| Low | High | Yellow LED on for link detected, flickers to indicate 10 Mbit activity |
| High | Low | One green LED on for link detected, flickers to indicate 100 Mbit activity |
| High | High | Two green LEDs on for link detected, flickers to indicate 1 Gbit activity |

12.3 Control wiring

Standard - 9 way D - Sensor connector (Female/Chassis Skt)

Recommended control cable: 7/0.2 mm 24AWG screened, circular. The cable screen should be earthed with a 360 deg connection to a conductive back-shell.




Figure 13 - Wiring the 9 way D sensor connector

Key to symbols












| | | | | | |
|---|------------------------|---|-------------------------|---|-------------------------|
|  | Run |  | Input |  | Keypad direction change |
|  | Stop |  | Output |  | Dry (no leak) |
|  | Clockwise rotation |  | Manual (keypad) control |  | Wet (leak detected) |
|  | Anticlockwise rotation |  | Analogue | | |

Table 4 - Wiring the D-Connector







| Signal Name | Input or output | Configurable | Signal response |
|---|-----------------|--------------|---|
|  <p>ANALOGUE #1</p> | Input | Yes |  <p>ANALOGUE #1</p>  <p>0-10V/ 4-20mA [34K/ 250R]</p> |
|  <p>ANALOGUE #2</p> | Input | Yes |  <p>ANALOGUE #2</p>  <p>0-10V/ 4-20mA [34K/ 250R]</p> |

Table 4 - Wiring the D-Connector











| Signal Name | Input or output | Configurable | Signal response |
|--|-----------------|--------------|--|
|  | Input | Yes |  |
|  | | | |
|  | Input | Yes |  |
|  | | | |

Table 4 - Wiring the D-Connector

| Signal Name | Input or output | Configurable | Signal response |
|--|-----------------|--------------|---|
|  | Input | Yes |  |
|  | Input | Yes |  |

12.4 N Module and F Module



Never apply mains power to the M12 connectors. Apply the correct signals to the terminals. Limit signals to the maximum values shown. Do not apply voltage across other terminals. Permanent damage, not covered by warranty, may result.



The recommended cable and cable glands must be used for the IP66 (NEMA 4X) version of the pump; otherwise ingress protection may be impaired.



Ensure that the module cover is correctly secured at all times by all screws supplied. Failure to do so may compromise the IP66 (NEMA 4X) protection.



Ensure that unused openings on the module are sealed using the blanking plugs provided. Failure to do so may compromise the IP66 (NEMA 4X) protection.




Figure 14 - N Module and F Module

1. M16 port

2. M16 port

3. M12 Connector - Ethernet connection

4. M12 Connector - Ethernet connection

Ethernet connection

There are two communication connectors on the rear of the N Module for Ethernet connection (3,4). Both connectors have the same pin configuration. The pin configuration and the signal response is shown below.

Plugs and cables for these connectors should be: M12, male, 4-Pin D coded, shielded.





Figure 15 - Ethernet connection

Adapter PCB

Figure 16 - Adapter PCB



1. Without isolated power supply option (N Module)

2. With isolated power supply option (F Module)

Note: Disconnect the adapter module by use of the ribbon eject levers. It is recommended to leave the 9W connector permanently attached to the pump.

Recommended control cable: metric = 0.05 sq mm - 1.31 sq mm solid and stranded. USA = 30AWG - 16AWG solid stranded. Cable: circular. Max/min outside diameter to ensure a seal when passed through the standard gland: 9.5 mm-5 mm. **The cable section must be circular to ensure a seal.**


Power supply options

The NEMA adapter board is available with an isolated power supply option (F-Module). This has a 24 V isolated power supply (maximum output load 80 mA), U1, fitted. As shown below, U1 completely separates the terminal 24 V and 0 V from the pump internal supplies.


The F-Module option may be used if the sensor requires an isolated supply or has a 4-20 mA output which cannot be used with the ground connected load resistor within the pump.

Figure 17 - Power supply options

1.



2.



1. Without isolated power supply option (N Module)

2. With isolated power supply option (F Module)

12.5 Input/output connectors

Key to symbols












| | | | | | |
|---|------------------------|---|-------------------------|---|-------------------------|
|  | Run |  | Input |  | Keypad direction change |
|  | Stop |  | Output |  | Dry (no leak) |
|  | Clockwise rotation |  | Manual (keypad) control |  | Wet (leak detected) |
|  | Anticlockwise rotation |  | Analogue | | |

Table 5 - Input/output Connectors






| Connector No. | Function | Input or output | Configurable | Signal response |
|---------------|---|-----------------|--------------|---|
| J1 |  | | No | Connection to pump |
| J2 |  | Input | Yes |  |
| J3 |  | Input | Yes |  |

Table 5 - Input/output Connectors

| Connector No. | Function | Input or output | Configurable | Signal response |
|---------------|----------------------------|-----------------|--------------|---|
| J4 | | Input | Yes | <div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;"> <p>START STOP 0 1 [5-24V] </p> </div> <div style="border: 1px solid black; padding: 5px;"> <p>LEAK 0 1 [5-24V] </p> </div> |
| J5 | | Input | Yes | <div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;"> <p>PRESSURE 0 1 [5-24V] </p> </div> <div style="border: 1px solid black; padding: 5px;"> <p>FREQ 5V-24V 1mA</p> </div> |
| J6 | <p>1.Earth 2.Earth</p> | | No | |

12.6 EtherNet/IP™ pump external interface parameters

Table 6 - External interface parameters

| Parameter | Limits | | | Units | Comment | |
|---|-------------------|-----|------|-------|---------|---------------------------------------|
| | Sym | Min | Nom | | | Max |
| Digital input voltage high | VD _{IH} | 5 | | 24 | V | Leak, Stop, PRESSURE_ALARM, Frequency |
| Digital input voltage low | VD _{IL} | 0 | | 0.8 | V | Leak, Stop, PRESSURE_ALARM, Frequency |
| Digital input voltage absolute maximum | VD _{in} | -30 | | 30 | V | Non operational |
| Digital input resistance | RD _{in} | 10 | | 110 | kΩ | 110K for ≤ 5 V |
| Frequency range | F _{max} | 1 | | 1000 | Hz | Frequency |
| Repetition rate | F _{max} | 1 | | 10 | Hz | Leak, Stop, Pressure |
| Analogue input, voltage mode | VA _{in} | -15 | 10 | 30 | V | 0-10 V range (100R source impedance) |
| Analogue input, voltage mode | RVA _{in} | | 34.4 | | kΩ | ±3 % |
| Analogue input measurement range | I _{in} | 0 | | 25 | mA | |
| Analogue input current absolute maximum | IA _{in} | -50 | | 28 | mA | Dissipation limit |
| Analogue input voltage absolute maximum | VA _{in} | 0 | | 7.0 | V | Dissipation limit |
| Analogue input resistance | RI _{IN} | | 250 | 270 | Ω | 250R Sense Res. |
| Analogue input filter bandwidth | BW | | 67 | | Hz | -6 dB Bandwidth |
| 22 V supply output | V _{aux} | | 18 | 30 | V | Un-regulated |
| 24 V isolated supply output | V24 | | 24 | | | |
| 22 V/24 V supply load current | | | | 80 | mA | Self-resetting fuse |

12.7 Network topology




Figure 18 - Star network







Figure 19 - Ring network



Figure 20 - Line topology

Table 7 - Allowance for one additional connection pair

| Cable type—100m maximum length | With NEMA module | Without NEMA module |
|---|------------------|---------------------|
| Cable with two connectors | | |
|  | ✓ | ✓ |
| Cable with one additional connector pair | | |
|  | ✓ | ✓ |
| Cable with two additional connector pairs | | |
|  | ✗ | ✓ |

13 Switching the pump on for the first time

1. Power up the pump. The pump displays the start-up screen with the Watson-Marlow Pumps logo for three seconds.




13.1 Selecting the display language

1. Use the \uparrow/\downarrow keys to select your chosen language, and press **SELECT**.



2. Your selected language will now be displayed on screen. Choose **CONFIRM** to continue. All text will now appear in your chosen language.



3. Choose **REJECT** to return to the language choice screen. This then proceeds to the home screen.



13.2 First-time start-up defaults



If the Auto Restart feature is enabled it may cause the pump to start as soon as power is turned on.

Auto Restart only affects operation of manual mode and EtherNet/IP™ mode.

If Auto Restart is enabled the "!" Symbol is shown on the screen to warn users that the pump may operate without any manual intervention (pump resumes with previous settings).

Do not use Auto Restart for more than:

- 1 mains power start per 3 minutes

We recommend remote control where a high number of starts is required.



If the pump is configured to Dispense or EtherNet/IP™ mode it will respond to remote commands at any time including immediately after power on. The pump may operate without any manual intervention (e.g. a remote setpoint could start the pump with no key press required).

The pump is preset with operational parameters as shown in table below.

Table 8 - First-time start-up defaults

| Parameter | 530 default |
|----------------------|---------------|
| Language | Not set |
| Default mode | Manual |
| Default manual speed | 220 rpm |
| Pump status | Stopped |
| Max speed | 220 rpm |
| Direction | CW |
| Pumphead | 520R2 |
| Tube size | 9.6 mm |
| Tube material | Bioprene |
| Flow calibration | 15.12 ml/rev |
| Flow units | rpm |
| Pump label | WATSON-MARLOW |
| Asset number | NONE |
| SG value | 1 |
| Keypad lock | Disabled |
| PIN protection | Not set |
| Keypad beep | ON |

Table 8 - First-time start-up defaults

| Parameter | 530 default |
|-------------------------|--------------------|
| PIN entry on start-up | ON |
| Remote start/stop input | High = stop |
| Leak detector input | High = leak |
| Dose adjust | 100% |
| Resume interrupted | OFF |

The pump is now ready to operate according to the defaults listed above.

Note: The display background colour changes according to running state as follows:

- White background indicates pump stopped
- Grey background indicates pump running
- Red background indicates error or alarm

All operating parameters may be changed by means of key-presses (see section "Pump operation" on page 16).

14 Switching the pump on in subsequent power cycles



If the **Auto Restart** feature is enabled it may cause the pump to start as soon as power is turned on.

Auto Restart only affects operation of manual mode and EtherNet/IP™ mode.

If **Auto Restart** is enabled the "!" Symbol is shown on the screen to warn users that the pump may operate without any manual intervention (pump resumes with previous settings).

Do not use **Auto Restart** for more than:

- 1 mains power start per 3 minutes

We recommend remote control where a high number of starts is required.



If the pump is configured to **Dispense** or **EtherNet/IP™** mode it will respond to remote commands at any time including immediately after power on. The pump may operate without any manual intervention (e.g. a remote setpoint could start the pump with no key press required).

Subsequent power-up sequences will jump from the start-up screen to the home screen.

- The pump runs a power-on test to confirm proper functioning of the memory and hardware. If a fault is found, an error code is displayed.
- The pump displays the start-up screen with the Watson-Marlow Pumps logo for three seconds followed by the home screen
- Start-up defaults are those in place when the pump was switched off last

Check that the pump is set to operate as you require it. The pump is now ready to operate.

All operating parameters may be changed by means of key-presses (see "Pump operation" on page 16).

Power interruption

This pump has an **Auto Restart** feature (which only affects **Manual** mode) which, when active, will restore the pump to the operating state it was in when power was lost.

Stop/start power cycles

Do not power up/power down the pump more than 20 times in an hour, whether manually or by means of the **Auto Restart** facility (which only affects **Manual** mode). We recommend remote control where a high frequency of power cycles is required.

15 Main menu

1. To access the **MAIN MENU** press the **MENU** button from one of the **HOME** screens or **INFO** screens.



2. This will display the **MAIN MENU** as shown below. Use the \wedge / \vee keys to move the selection bar between the available options.
3. Press **SELECT** to choose an option.

4. Press **EXIT** to return to the screen from where the MENU was called.



15.1 Security settings

Security settings can be changed by selecting **SECURITY SETTINGS** from the Main menu.


Auto keypad lock

Note: Auto keypad lock is not supported in **Dispense** mode.

1. Press **ENABLE/DISABLE** to switch on/off the Auto keypad lock. When active the keypad will lock after 20 seconds of inactivity.



2. Once locked it will display the screen below when any key is pressed. To unlock the keypad press the two **UNLOCK** keys together.



- The padlock icon will appear on the operating mode home screen to show that keypad lock is activated.



- Note that the **STOP** key will always work whether the keypad is locked or not.

PIN protection

Using the \wedge / \vee keys select **PIN protection** from the **SECURITY SETTINGS** menu and press **ENABLE/DISABLE** to switch on/off the PIN protection. If PIN protection has been enabled, a Master level PIN will be required to disable PIN lock.

Setting Master PIN

PIN will enable after one minute from the last time the PIN was entered.

Setting the Master PIN protects all functionality. The Master is able to selectively enable functionality for two additional operators. These are defined as User 1 and User 2. They will be able to access this functionality by entering a PIN code assigned to them by the Master user.

- To set the Master PIN, scroll to **Master level** and press **ENABLE**.




2. To define a four digit Master PIN, use the \wedge / \vee keys to select each digit from 0-9. Once you have the required digit press the **NEXT DIGIT** key. After selecting the fourth digit press **ENTER**.



3. Now press **CONFIRM** to check that the number entered is the PIN you require. Press **CHANGE** to return to PIN entry.



- The following screen will be displayed to indicate that the Master PIN has been applied to access all functionality. Press **NEXT** to selectively enable functionality access for User 1 and User 2.



Configure User 1 security settings


- The **PIN PROTECTION** level screen will be displayed with **User 1** highlighted, press **ENABLE** to configure User 1 security settings or scroll to configure an alternative User.



2. **ENABLE** user 1 security settings displays the PIN entry screen for User 1. To define a four digit User 1 PIN, use the \wedge / \vee keys to select each digit from 0-9. Once you have the required digit press the **NEXT DIGIT** key. After selecting the fourth digit press **ENTER**.



3. Now press **CONFIRM** to verify that the number entered is the PIN you require. Press **CHANGE** to return to PIN entry.



4. To define the allowed functionality, use the \wedge / \vee keys to select the functionality and press **ENABLE**. User 1 PIN will allow access to only the enabled functionality, to disable functionality, highlight the enabled functionality and press **DISABLE**. When all the required functionality has been enabled, press **FINISH**.



Configure User 2 security settings


1. The **PIN PROTECTION LEVEL** screen will be displayed with **User 2** highlighted, press **ENABLE** to configure User 2 security settings or scroll to configure an alternative User.



2. **ENABLE** user 2 security settings displays the PIN entry screen for User 2. To define a four digit User 2 PIN, use the **^**/**v** keys to select each digit from 0-9. Once you have the required digit press the **NEXT DIGIT** key. After selecting the fourth digit press **ENTER**.



- To define the allowed functionality, use the \wedge / \vee keys to select the functionality and press **ENABLE**. User 2 PIN will allow access to only the enabled functionality, to disable functionality, highlight the enabled functionality and press **DISABLE**. When all the required functionality has been enabled, press **FINISH**.



Note: Once Security Settings for User 1 and User 2 have been set by the Master, only the Master PIN will allow access to Security Settings.


- The **HOME** screen will be displayed. A PIN is now required to access all functionality. The Master PIN accesses all pump functionality and the User 1 and User 2 PINs access only the defined functionality. To enter the PIN, use the \wedge / \vee keys to select each digit from 0-9. Once you have the required digit press the **NEXT DIGIT** key. After selecting the fourth digit press **ENTER**.




5. If an incorrect PIN has been entered the following screen will be displayed. NOTE: this screen will also display if the PIN entered does not allow access to that functionality.



6. If a PIN number is entered that is already in use, the following screen will be displayed, press **CHANGE** to input an alternative PIN or **EXIT** to abort



7. If the PIN entered does not allow access to the functionality the following screen will be displayed.



Keypad beep

1. From **SECURITY SETTINGS** scroll to **Keypad beep** using the \wedge / \vee keys and select **ENABLE**. The pump will now beep at every key press.



PIN entry on start-up

The setting **PIN entry during start-up** can be used to configure the software to choose if PIN entry is required during start up.

This feature also means that **Auto Restart** capability is now independent of PIN code entry after start up.

If this setting is enabled ✓ then the pump will require the PIN code to be entered before the pump will enter the home control screen after a power cycle.

If this setting is disabled ✗ then the pump will not require the PIN code to be entered before the pump will enter the home control screen after a power cycle.

The **Auto Restart** response of the pump after a power cycle is now independent of PIN entry.

The default setting, is enabled ✓ so a PIN code will be required after a power cycle before the pump will enter the home control screen.

Disabling this feature does not change any other aspects of PIN code operation. Anyone wishing to modify pump settings will still need to enter the PIN code.

15.2 General settings

To view the general settings menu, select **GENERAL SETTINGS** from the main menu.

Auto restart

This pump includes a feature called **Auto Restart**. This setting only applies to pump operation in **Manual** mode.

If the pump is operating in manual mode and this feature is enabled (configured to **yes**), it will change the way the pump responds to a power cycle.

When **Auto Restart** is enabled it will cause the pump to remember it's current operating settings when power is lost and to resume using these as soon as power comes back on.

The ! symbol is also displayed when the **Auto Restart** feature is enabled to warn users that the pump has been configured in a way that could result in unexpected operation.

1. Press **ENABLE/DISABLE** to turn the **Auto Restart** feature on/off (**Manual** mode).



Do not use Auto Restart for more than 20 mains power starts per hour. We recommend remote control where a high number of starts is required.

If the Auto Restart feature is enabled it may cause the pump to start as soon as power is turned on.

Auto Restart only affects operation of manual mode and EtherNet/IP™ mode. If Auto Restart is enabled the "!" Symbol is shown on the screen to warn users that the pump may operate without any manual intervention (pump resumes with previous settings).

Do not use Auto Restart for more than:

- 1 mains power start per 3 minutes

We recommend remote control where a high number of starts is required.



If the pump is configured to Dispense or EtherNet/IP™ mode it will respond to remote commands at any time including immediately after power on. The pump may operate without any manual intervention (e.g. a remote setpoint could start the pump with no key press required).



Flow units

The current chosen flow unit is displayed on the right hand side of the screen. To change flow units move the selection bar over the flow unit menu entry and press **SELECT**.

1. Use the \wedge / \vee keys to move the selection bar over the required flow unit, then press **SELECT**. All flow rates displayed on screens will now be in the chosen units.



- If a mass flow unit is selected, the specific gravity of the fluid must be entered. The following screen is displayed.



- Use the \wedge \vee keys to enter the value of the specific gravity, and press **SELECT**.

Pump label

The pump label is a user defined 20 digit alphanumeric label which is displayed in the header bar of the home screen. To define or edit the pump label, move the selection bar over the Pump label menu entry and press **SELECT**. If a pump label has been previously defined, this will be displayed on screen to allow editing, otherwise it will display the default label "WATSON-MARLOW".

- Use the \wedge \vee keys to scroll through the available characters for each digit. The available characters are 0-9, A-Z and SPACE.



2. Press **NEXT** to move onto the next character, or **PREVIOUS** to move back to the previous character.



3. Press **FINISH** to save the entry and return to the general settings menu.



Asset number

The Asset number is for users to set a unique asset identification code for the pump. This can help to track pumps on the network and distinguish between different pumps on the network. There is no default factory setting for this parameter and new pumps are supplied without an asset number.

Setting up the asset number.

1. From the main menu, using the \wedge / \vee keys, scroll to **General settings** and press **SELECT**.



2. Using the \wedge / \vee keys, scroll to **Asset number** and press **SELECT**.



3. Using the \wedge / \vee keys, enter a character.



4. There are 20 character slots. Press **NEXT** to confirm your character and to move onto the next. Press **PREVIOUS** to return to the last character slot.



- Once you have filled the character slots press **FINISH**. This will return you to the **GENERAL SETTINGS** screen.



- Power the pump off and on again to apply the asset number.

Failsafe speed

A failsafe speed is a dedicated speed the pump uses if an error occurs. Use this to prevent the pump stopping in the event of an error.

Example: disconnect the RJ45 cable from the pump while running on EtherNet/IP™ mode and the pump will error.

- If failsafe speed is enabled, the pump will run at the failsafe speed and the network error message will display.
- If failsafe speed is not enabled, the pump will stop running and the network error message will display.

Once the error is acknowledged, the pump will run as normal.

Pumphead type


- Select **GENERAL SETTINGS** from the main menu.



- Use the \wedge / \vee keys to move the selection bar over **Pumphead type** and press **SELECT**. The following screen will be displayed.



- Use the \wedge / \vee keys to move the selection bar over **Pumphead** and press **SELECT**.



- Use the \wedge / \vee keys to move the selection bar over the required pumphead type and press **SELECT**.



Tube size and tube material

- Select **Tube size** from **GENERAL SETTINGS**, then use the \wedge / \vee keys to move the selection bar over **Bore size** and press **SELECT**.



2. Use the \wedge / \vee keys to move the selection bar over the tube size to be used and press **SELECT**.



3. If a LoadSure element has been selected then the tube size is displayed as pressure and bore.



4. This screen also allows you to select the tube material used. Use the \wedge / \vee keys to move the selection bar over **Tube material** and press **SELECT**.



5. Use the \wedge / \vee keys to move the selection bar over the tube material to be used and press **SELECT**.



6. The **PUMPHEAD MODEL** screen allows the tube Lot Number to be recorded for future reference. Using the \wedge / \vee keys, scroll to **Tube lot number** and press **SELECT**.
7. Use the \wedge / \vee keys to scroll through the available characters for each digit. The available characters are 0-9, A-Z, and SPACE.



8. Press **NEXT** to move onto the next character, or **PREVIOUS** to move back to the last character.



9. Press **FINISH** to save the entry and return to the general settings menu.

Restore defaults

1. To restore the factory default settings select **Restore defaults** from the **GENERAL SETTINGS** menu.
2. There are two confirmation screens to ensure that this function is not carried out in error.
3. Press **CONFIRM** followed by **RE-CONFIRM** to restore the defaults.



Language

1. Select language from the **GENERAL SETTINGS** menu to choose an alternative display language for the pump. The pump must be stopped before changing the language.

- Using the \wedge / \vee keys, scroll to your required language. Press **SELECT** to confirm.



- Your selected language will now be displayed on screen. Press **CONFIRM** to continue, all displayed text will now appear in your chosen language.
- Press **REJECT** to return to the language choice screen.



15.3 Change mode

Selecting **CHANGE MODE** menu from the main menu will navigate you to access the sub-menu shown below. This is the same as pressing the **MODE** key. Please see "Mode menu " on page 70 for further details.

15.4 Control settings

1. Select **CONTROL SETTINGS** from the **MAIN MENU** to access the sub menu shown below. Use the \wedge / \vee keys to move the selection bar. Press **SELECT** to choose the required function.



Speed limit

The maximum speed the pump is capable of running at is 220 rpm.

1. Select **Speed limit** from the **CONTROL SETTINGS** menu to define a lower maximum speed limit for the pump. This speed limit will be applied to all operating modes.
2. Use the \wedge / \vee keys to adjust the value and press **SAVE** to set.

Reset run hours

1. Select **Reset run hours** from the **CONTROL SETTINGS** menu.
2. Select **RESET** to zero the run hours counter. The run hours counter can be viewed by pressing **INFO** from your home screen. The following screen will be displayed. Press **RESET** to reset the run hours or **CANCEL** to return to the **CONTROL SETTINGS** menu.



15.5 Help

Help


1. Select Help from the main menu to access the help screens.



| SOFTWARE VERSIONS | BOOTLOADER VERSIONS |
|---------------------------------|-----------------------------|
| Main Processor Code: 1.2 | Main Processor Code: 1.2 |
| HMI Processor Code: 1.2 | HMI Processor Code: 1.2 |
| HMI Screen Resources: 1.2 | |
| PROSABUS Processor Code: 1.2 | |
| BOOTLOADER BACK | BOOTLOADER BACK |

16 Mode menu

1. Press **MODE** to display the **CHANGE MODE** menu.
2. Use the \wedge / \vee keys to scroll through the available modes.
 - **Manual (default)**
 - **Flow Calibration**
 - **EtherNet/IP™**
 - **Dispense**
 - **BACK**
3. Use **SELECT** to choose mode. Use the right hand function key to alter mode settings.



17 Manual

All settings and functions of the pump in **Manual** mode are set and controlled by means of key-presses. Immediately after the start-up display sequence detailed in: "Switching the pump on in subsequent power cycles " on page 41, the **Manual** mode home screen will be displayed unless **Auto Restart** is enabled.

If **Auto Restart** is enabled the pump will return to the last known settings when the power is re-applied. When the pump is running it displays an animated clockwise arrow. In normal operation, the direction of flow is into the bottom port of the pumphead and out of the top port.

If an exclamation mark (!) is displayed, it indicates that the pump could automatically restart at any time. In **Manual** mode, the **Auto Restart** behaviour is configurable. If a padlock icon shows, it indicates that the keypad lock is on.

17.1 Start

1. Starts the pump, and the display background changes to grey. If the pump is already running, pressing this has no effect.



17.2 Stop

1. Stops the pump. The display background changes to white. If the pump is not running pressing this has no effect.



17.3 Increasing and decreasing flow rate

1. Using the \wedge / \vee keys will increase or decrease the flow rate.



Decreasing flow rate

- A single key press will decrease flow rate by the least significant digit of the chosen flow rate unit.
- Repeat key presses as required to achieve the desired flow rate.
- Hold down the key for flow rate scrolling.

Increasing flow rate

- A single key press will increase flow rate by the least significant digit of the chosen flow rate unit.
- Repeat key presses as required to achieve the desired flow rate.
- Hold down the key for flow rate scrolling.

MAX FUNCTION (Manual mode only)

1. Using the MAX key:




- Press and hold the **MAX** key to run at maximum flow.
- Release the key to stop the pump.
- The volume pumped and time elapsed are displayed while the **MAX** key is pressed and held.

18 Flow calibration

This pump displays flow rate in ml/min.

18.1 Setting the flow calibration

1. Using the \wedge / \vee keys, scroll to **Flow calibration** and press **CALIBRATE**.




2. Using the \wedge / \vee keys, enter the maximum flow rate limit and press **ENTER**.



3. Press **START** to begin pumping a volume of fluid for calibration.




4. Press **STOP** to stop pumping fluid for the calibration.



5. Use the \wedge / \vee keys to enter the actual volume of fluid pumped.



6. To accept the new calibration press **ACCEPT** or **RE-CALIBRATE** to repeat the procedure. Press **HOME** or **MODE** to abort.



7. The pump is now calibrated.

19 EtherNet/IP™ mode

19.1 Configure EtherNet/IP™ settings

Configure the settings to suit your network. The following is an example of a static IP address:

Table 9 - Configure EtherNet/IP™ settings

| Setting | Value |
|-----------------|-----------------|
| DHCP Enable | Off |
| IP Address | 192.168.001.012 |
| Subnet mask | 255.255.255.000 |
| Gateway address | 192.168.001.001 |


1. Press the **MODE** key to access the **MODE** menu.



2. Use the \wedge / \vee keys to select **EtherNet/IP™**.




3. Press the **SELECT** key to use **EtherNet/IP™** mode.



4. Press the **SETTINGS** key to access the **ETHERNET/IP™ SETTINGS** menu.

Setting DHCP Enable

1. Press the **DISABLE** key to set **DHCP Enable** to **Off**.



Setting the IP Address, Subnet mask and Gateway address

Configure each of the IP Address, subnet mask and gateway address in turn using the following method:

1. Use the \wedge / \vee keys to select the setting to configure. Press **SET** to enter the **SET ADDRESS** menu.



2. Use the \wedge / \vee keys to set the first number. Hold the \wedge / \vee key increase the scrolling speed. Press **NEXT** to move to the next number.



3. After setting the last number, press **CONFIRM** to store the number and return to the **ETHERNET/IP™ SETTINGS** screen.

4. Press **BACK** to return to the **MODE MENU**.



19.2 EtherNet/IP™ mode

1. From the **CHANGE MODE** menu, highlight **EtherNet/IP™** and press **SELECT** to use **EtherNet/IP™** mode.



2. The pump display will show a network error as indicated above if the pump is not connected to a PC.



3. If the pump is connected to a PC, press **INFO** to display the network settings.

19.3 Pump parameters

Setting parameters

To set a parameter to a new value:

- Type a value into the field or click on the check box (depending on the parameter type).
- Click **set** to store the new value or click **refresh** to cancel the change.
- Up to 100 parameters are displayed per page. Use the < and > buttons to navigate between pages.

Table 10 - Cyclic parameters

| Index | Name | Access | Type | Description |
|-------|--------------------|--------|--------|---|
| 1 | SetFlowCal | Write | UInt32 | Set the flow calibration value ($\mu\text{L}/\text{rev}$) |
| 2 | SetSpeed | Write | UInt16 | Speed is set in Deci RPM. Max speed depends on head type. See Pump Head enumeration table |
| 3 | SetSpeedLimit | Write | UInt16 | Speed is set in Deci RPM. Max speed depends on head type. See pump head table below. |
| 4 | SetFailsafeSpeed | Write | UInt16 | If the failsafe is enabled the pump will run continuously at the selected speed in the event of a communications loss. |
| 5 | SetFailsafeEnable | Write | Bool | Enabled the failsafe speed. If disabled the pump will stop in the event of a communications loss. If enabled the pump will run at the speed set in the "SetFailsafeSpeed" parameter |
| 6 | SetReverse | Write | Bool | If set the pump will run anti-clockwise. Pump defaults to clockwise rotation |
| 7 | Run | Write | Bool | Set to 1 (true) to allow the pump to run. 0 will stop the pump. Note that pump enable needs to be set |
| 8 | RunEnable | Write | Bool | Need to set to 1 to allow pump to run. Setting to 0 will stop the pump and not allow the pump to run. |
| 9 | ResetRunHours | Write | Bool | Resets the run hours accumulator |
| 10 | PauseFlowTotaliser | Write | Bool | Set to 1 to pause the internal FlowTotaliser parameter. Setting to 0 will un-pause the parameter |
| 11 | ResetFlowTotaliser | Write | Bool | Set to 1 to reset the flow totaliser. Set to 0 to allow the flow totaliser to accumulate |

Table 10 - Cyclic parameters

| Index | Name | Access | Type | Description |
|--------------|--------------------------|---------------|-------------|--|
| 12 | ResetRevolutionCount | Write | Bool | Set to 1 to reset the revolution count. Set to 0 to allow the revolution count to increment. |
| 13 | FlowCal | Read | UInt32 | Reports the Flow calibration value in μL . |
| 14 | RunHours | Read | UInt32 | Reports the number of hours the pump has run |
| 15 | SensorFlowRate | Read | SInt32 | Reports a value if the flow sensor is setup |
| 16 | SensorPressure | Read | SInt32 | Reports a value if the pressure sensor is setup |
| 17 | PressureLo-HiWarningSp | Read | SInt32 | Displays the Pressure low warning band set point in deci-psi |
| 18 | PressureHi-LoWarningSp | Read | SInt32 | Displays the Pressure high warning band set point in deci-psi |
| 19 | PressureLo-LoAlarmSp | Read | SInt32 | Displays the Pressure low alarm band set point in deci-psi |
| 20 | PressureHi-HiAlarmSp | Read | SInt32 | Displays the Pressure high alarm band set point in deci-psi |
| 21 | FlowSensorLo-HiWarningSp | Read | SInt32 | Displays the Flow low warning band set point in μL |
| 22 | FlowSensorHi-LoWarningSp | Read | SInt32 | Displays the Flow high warning band set point in μL |
| 23 | FlowSensorLo-LoAlarmSp | Read | SInt32 | Displays the Flow low alarm band set point in μL |
| 24 | FlowSensorHi-HiAlarmSp | Read | SInt32 | Displays the Flow high alarm band set point in μL |
| 25 | FlowTotaliser | Read | UInt32 | Displays the totalised flow value in deci-ml |

Table 10 - Cyclic parameters

| Index | Name | Access | Type | Description |
|-------|-------------------|--------|--------|---|
| 26 | RevolutionCount | Read | UInt32 | Displays the revolution count in full rotations |
| 27 | PumpSpeed | Read | UInt16 | Displays the current pump speed set point in deci rpm |
| 28 | SpeedLimit | Read | UInt16 | Displays the current speed limit set point in deci rpm |
| 29 | GeneralAlarm | Read | UInt16 | Bit 0 Motor Stall Error Bit 1 Motor Speed error Bit 2 Over Current Error Bit 3 Over Voltage Error Bit 4 Guard open (only on guard enabled versions) Bit 5 Leak Detected Bit 6 Dispense interrupted Bit 7 Pressure Switch |
| 30 | PumpVersionMajor | Read | UInt8 | Pump software version major revision number |
| 31 | PumpVersionMinor | Read | UInt8 | Pump software version minor revision number |
| 32 | ASIC-VersionMajor | Read | UInt8 | Ethernet ASIC software version major revision number |
| 33 | ASIC-VersionMinor | Read | UInt8 | Ethernet ASIC software version minor revision number |
| 34 | ASIC-VersionBuild | Read | UInt8 | Ethernet ASIC software build revision number |
| 35 | WallSize | Read | Enum | Displays the currently selected tube wall size. Please see WallSize enum table below |

Table 10 - Cyclic parameters

| Index | Name | Access | Type | Description |
|--------------|---------------------|---------------|-------------|--|
| 36 | BoreSize | Read | Enum | Displays the currently selected tube bore size. Please see BoreSize enum table below |
| 37 | PumpModel | Read | Enum | Displays the currently selected pump model. Please see PumpModel enum table below |
| 38 | PumpHead | Read | Enum | Displays the currently selected pump head. Please see PumpHead enum table below |
| 39 | PressureSensorModel | Read | Enum | Displays the currently selected pressure sensor model. Please see PressureSensorModel enum table below |
| 40 | PressureSensorSize | Read | Enum | Displays the currently selected pressure sensor size. Please see PressureSensorSize enum table below |
| 41 | FlowSensorModel | Read | Enum | Displays the currently selected flow sensor model. Please see FlowSensorModel enum table below |
| 42 | FlowSensorSize | Read | Enum | Displays the currently selected flow sensor size. Please see FlowSensorSize enum table below |
| 43 | Reverse | Read | Bool | If set the pump is set to run Counter-Clockwise |
| 44 | Running | Read | Bool | Set if the pump is running |
| 45 | LeakDetected | Read | Bool | Set if a leak is detected |
| 46 | MotorStallError | Read | Bool | If Set the pump has a Motor Stall Error. Please follow onscreen instructions |
| 47 | MotorSpeedError | Read | Bool | If set the pump has an over current error. Please follow onscreen instructions |

Table 10 - Cyclic parameters

| Index | Name | Access | Type | Description |
|--------------|---------------------|---------------|-------------|--|
| 48 | OverCurrentError | Read | Bool | If set the pump has an over current error. Please follow onscreen instructions |
| 49 | OverVoltageError | Read | Bool | If set the set the pump has an over voltage error. Please follow onscreen instructions |
| 50 | Guard/Interlock | Read | Bool | If set then the guard has been opened. Please follow onscreen instructions to clear. |
| 51 | FlowHi-LoActive | Read | Bool | If set then the flow sensor low warning is active |
| 52 | FlowLo-LoActive | Read | Bool | If set the flow sensor low alarm is active |
| 53 | PressureHi-LoActive | Read | Bool | If set the pressure low warning is active |
| 54 | PressureLo-LoActive | Read | Bool | If set the pressure low alarm is active |
| 55 | FlowHi-HiActive | Read | Bool | If set the flow high alarm is active |
| 56 | FlowLo-HiActive | Read | Bool | If set the flow high warning is active |
| 57 | PressureHi-HiActive | Read | Bool | If set the pressure high alarm is active |
| 58 | PressureLo-HiActive | Read | Bool | If set the pressure high warning is active |
| 59 | FlowSensorError | Read | Bool | If set there is an error condition on sensor input 1 |
| 60 | PressureSensorError | Read | Bool | If set there is an error condition on sensor input 2 |
| 61 | AnybusNetworkMode | Read | Bool | If set the pump is in Ethernet IP Mode |
| 62 | AnybusNetworkActive | Read | Bool | If set Ethernet IP is active on the device |
| 64 | ErrorAcknowledge | Write | Bool | Used to acknowledge errors over EtherNet IP |
| 106 | PressureSwitchError | Read | Bool | Reports the current active batch by ID |

Table 10 - Cyclic parameters

| Index | Name | Access | Type | Description |
|-------|----------|--------|--------|--|
| 200 | RPIRange | Read | SInt32 | Reports the timings for cyclic data access |

Table 11 - Acyclic Parameters

| Index | Name | Access | Type | Description |
|-------|----------------------------|--------|--------|--|
| 63 | Asset Number | Read | Char | If set, will read the created asset number |
| 70 | EditRecipeVolume | Write | UInt32 | Edit active recipe volume set in μL |
| 71 | EditRecipePumpSpeed | Write | UInt16 | Edit active Recipe dispense speed set in DeciRPM |
| 72 | EditBatchSize | Write | UInt16 | Edit active Batch size (0 sets unlimited batch) |
| 73 | Edit Batch Start Delay | Write | UInt16 | Set the time delay between the batch start and the first dose |
| 74 | EditBatchEndDelay | Write | UInt16 | Set the time delay between the last dose in a batch and the end of the batch |
| 75 | Edit RecipeStart Delay | Write | UInt16 | Set the time delay between the start of the dose and the pump head starting |
| 76 | EditRecipeEndDelay | Write | UInt16 | set the time delay between the pump head stopping and the end of the dose |
| 78 | EditBatchDispenseDirection | Write | UInt8 | Set batch pump direction to anti clock wise if set |
| 79 | EditRecipeAntiDripAmount | Write | UInt8 | Edit the recipe anti drip amount |

Table 11 - Acyclic Parameters

| Index | Name | Access | Type | Description |
|-------|---|--------|--------|---|
| 80 | EditBatchName | Write | Char | Edit the name of the active batch |
| 81 | EditRecipeName | Write | Char | Edit the name of the recipe in the active batch |
| 82 | ActiveRecipeID | Read | UInt32 | Reports the current active recipe by ID |
| 83 | ActiveRecipeVolume | Read | UInt32 | Reports the current target volume |
| 84 | ActiveRecipeFlowRate | Read | UInt32 | Reports the current target flow rate |
| 85 | ActiveBatchSize | Read | UInt16 | Reports the current batch size |
| 86 | ActiveBatchStartDelay | Read | UInt16 | Reports the current batch start delay |
| 87 | ActiveBatchEndDelay | Read | UInt16 | Reports the current batch end delay |
| 88 | ActiveRecipeStartDelay | Read | UInt16 | Reports the current recipe start delay |
| 89 | ActiveRecipeEndDelay | Read | UInt16 | Reports the current recipe end delay |
| 90 | CurrentDispenseDoseDelivered | Read | UInt16 | Reports the current number of doses delivered |
| 92 | ActiveRecipeAntiDripAmount | Read | UInt8 | Reports the current anti-drip amount |
| 93 | CurrentDispenseDoseAdjustmentPercentage | Read | UInt8 | Reports the current dose adjustment value |
| 94 | ActiveBatchName | Read | Char | Read the active batch name |
| 95 | ActiveRecipeName | Read | Char | Read the active recipe name |

Table 11 - Acyclic Parameters

| Index | Name | Access | Type | Description | |
|-------|------------------|--------|--------|--|--|
| 104 | DispenseBitField | Read | UInt8 | Bit 0 | Active batch ID invalid, if set active batch ID is invalid |
| | | | | Bit 1 | Active recipe ID invalid, if set active recipe ID is invalid |
| | | | | Bit 2 | Active Batch Motor Direction is anti-clockwise, if set batch motor direction is anti-clockwise |
| 105 | ActiveBatchId | Read | UInt32 | Reports the current active batch by ID | |

Table 12 - PumpModel

| Enum Number | PumpModel |
|-------------|-----------|
| 0 | 530 |
| 1 | 630 |
| 2 | 730 |

Table 13 - PumpHead

| Enum Number | Pumphead | Default speed | Comments |
|--------------------|-----------------|----------------------|--|
| 0 | 505CA | 0.1-220 rpm | |
| 1 | 313D | 0.1-220 rpm | |
| 2 | 313D2 | 0.1-220 rpm | |
| 3 | 314D | 0.1-220 rpm | |
| 4 | 314D2 | 0.1-220 rpm | |
| 5 | 520R | 0.1-220 rpm | |
| 6 | 520R2 | 0.1-220 rpm | |
| 7 | 505L Continuous | 0.1-220 rpm | |
| 8 | 505L Double | 0.1-220 rpm | |
| 9 | 520 Sanitary | 0.1-220 rpm | |
| 10 | 520 Industrial | 0.1-220 rpm | |
| 11 | 620R | 0.1-265 rpm | Default is 0.1-165 rpm. Max speed can be adjusted to 265 rpm using the max speed parameter or screen |
| 12 | 620L Continuous | 0.1-265 rpm | |
| 13 | 620L Double | 0.1-265 rpm | |
| 14 | 620RE Sanitary | 0.1-265 rpm | |
| 15 | 620RE4 Sanitary | 0.1-265 rpm | |

Table 13 - PumpHead

| Enum Number | Pumphead | Default speed | Comments |
|--------------------|----------------------|----------------------|-----------------|
| 16 | 620RE Industrial | 0.1-265 rpm | |
| 17 | 620RE4 Industrial | 0.1-265 rpm | |
| 18 | 720R | 0.1-360 rpm | |
| 19 | 720 Sanitary | 0.1-360 rpm | |
| 20 | 720 Industrial | 0.1-360 rpm | |

Table 14 - Wallsize

| Enum Number | WallSize | Comments |
|--------------------|-----------------|-----------------|
| 0 | 0.8 mm | |
| 1 | 1.6 mm | |
| 2 | 2.4 mm | |
| 3 | 2.8 mm | |
| 4 | 3.2 mm | |
| 5 | 4.0 mm | |
| 6 | 4.8 mm | |

Table 15 - BoreSize

| Enum Number | BoreSize | Comments |
|--------------------|-----------------|-----------------|
| 0 | 0.13 mm | |
| 1 | 0.19 mm | |
| 2 | 0.25 mm | |
| 3 | 0.38 mm | |
| 4 | 0.50 mm | |
| 5 | 0.63 mm | |
| 6 | 0.76 mm | |
| 7 | 0.80 mm | |
| 8 | 0.88 mm | |
| 9 | 1.02 mm | |
| 10 | 1.14 mm | |
| 11 | 1.29 mm | |
| 12 | 1.42 mm | |
| 13 | 1.52 mm | |
| 14 | 1.60 mm | |
| 15 | 1.65 mm | |
| 16 | 1.85 mm | |
| 17 | 2.05 mm | |
| 18 | 2.29 mm | |
| 19 | 2.54 mm | |
| 20 | 2.79 mm | |
| 21 | 3.20 mm | |
| 22 | 4.80 mm | |
| 23 | 6.40 mm | |
| 24 | 8.00 mm | |
| 25 | 9.60 mm | |
| 26 | 12.0 mm | |

Table 15 - BoreSize

| Enum Number | BoreSize | Comments |
|-------------|----------|----------|
| 27 | 12.7 mm | |
| 28 | 15.9 mm | |
| 29 | 16.0 mm | |
| 30 | 17.0 mm | |
| 31 | 19.0 mm | |
| 32 | 25.4 mm | |

Table 16 - PressureSensorModel

| Enum Number | Pressure Sensor Model | Comments |
|-------------|-----------------------|----------|
| 0 | None | |
| 1 | Press-N-0xx | |
| 2 | Parker Scilog | |
| 3 | Generic Pressure | |
| 4 | Balluff BSP Series | |

Table 17 - PressureSensorSize

| Enum Number | Pressure Sensor Size | Comments |
|-------------|----------------------|----------|
| 0 | None | |
| 1 | PRESS_N_SIZE_025 | |
| 2 | PRESS_N_SIZE_038 | |
| 3 | PRESS_N_SIZE_050 | |
| 4 | PRESS_N_SIZE_075 | |
| 5 | PRESS_N_SIZE_100 | |

Table 18 - FlowSensorModel

| Enum Number | Flow Sensor Model | Comments |
|-------------|-------------------------------------|----------|
| 0 | None | |
| 1 | C0.55 V2.0 | |
| 2 | Em-tec BioProTT | |
| 3 | FlexMag 4050C | |
| 4 | Generic Flow | |
| 5 | IFM SM4000, SM6000, SM7000 & SM8000 | |

Table 19 - FlowSensorSize

| Enum Number | Flow Sensor Size | Comments |
|-------------|------------------|----------|
| 0 | None | |
| 1 | 4050C_SIZE_38 | |
| 2 | 4050C_SIZE_12 | |
| 3 | 4050C_SIZE_34 | |
| 4 | 4050C_SIZE_1 | |

19.4 EDS compatibility guide

Table 20 - EDS compatibility guide

| EDS file (Found on website) | EDS release Date | Pump Models | Compatible with pump software versions | Version comments |
|---|---------------------|---------------------------|---|--|
| 530/630/730 EtherNet/IP EDS Rev 2.1 control file | March 2020 | 530En, 630En, 730En | 0.26.02 | Initial EDS release |
| 530/630/730 EtherNet/IP EDS Rev 2.2 control file | November 2020 | 530En, 630En, 730En | 0.27.04 0.27.05 | Addition of asset number (parameter 63), Error Acknowledge (parameter 64), RPI range (parameter 65), parameter re- ordering |

Table 20 - EDS compatibility guide

| EDS file (Found on website) | EDS release Date | Pump Models | Compatible with pump software versions | Version comments |
|---|-----------------------------|---------------------------|---|---|
| 530/630/730 EtherNet/IP EDS Rev 2.5 control file | January 2021 | 530En, 630En, 730En | 0.41.03 | Addition of PressureSwitchError (parameter 106), use of bit 7 in general alarm for PressureSwitchError, use of bit 6 in general alarm for DispenseInturrupted, AssetNumber (parameter 63) moved to acyclic data records, parameter 61 and 62 name change to AnybusNetworkMode and AnybusNetworkActive, |

Link to EDS file location:

1. Navigate to: <https://www.wmftg.com/en/literature/other-resources/software-and-devices/>

Notes:

1. If your pump software is compatible with multiple EDS files versions it is recommended to use the latest version available.
2. In order to find your pump software version, select **Help**, then **Software** on your pump
3. The correct EDS file version must be used in combination with the pump software versions listed for good communication between the pump and control system.
4. Networks using pumps with different software and EDS versions are acceptable as long as each pump is using the correct EDS version

20 Dispense mode

In this mode, the pump will dispense a batch of doses of the specified volume.

Follow these steps to use **Dispense** mode:

1. "Create a new recipe or edit a recipe" below
2. "Create a new batch or edit a batch" on page 100
3. "Set the active batch" on page 104
4. "Start dispensing" on page 106



20.1 Create a new recipe or edit a recipe

Note: the pump must be stopped to enter **DISPENSE SETTINGS**.

1. Press **MODE** to display the **CHANGE MODE** menu.



2. Using the \wedge / \vee keys, scroll to **Dispense** and press **SETTINGS**



3. Using the \wedge / \vee keys, scroll to **Recipes** and press **SELECT**.



4. Using the \wedge / \vee keys, scroll to **Add new recipe** and press **SELECT** to create a new recipe. The **ADD RECIPE** screen is displayed. Alternatively scroll to a recipe name and press **SELECT** to edit that recipe. The **EDIT RECIPE** screen is displayed.



Press **SELECT** to edit a parameter. Set each parameter to the desired value. See "Recipe parameters" on page 109 for a description of the parameters.



5. To enter a recipe name:

- Using the \wedge/\vee keys, enter a character.
- Press **NEXT** to confirm your character and to move onto the next. Press **PREVIOUS** to move the cursor back one character.
- Move the cursor to the end or beginning of the entry field using **NEXT** or **PREVIOUS**. When the cursor is at the beginning or end of the entry field, press **FINISH** to store the entry.



6. Use the \wedge/\vee key to highlight any of the remaining parameters and press **SELECT**.
7. Use the \wedge/\vee keys to adjust the value as desired and press **SET**.
8. If you have created a new recipe highlight **Save** and press **SELECT**.
9. If you have edited an existing recipe highlight **Save** and press **SELECT** to overwrite or to save as a new recipe highlight **Save as** and press **SELECT**.
10. Press **FINISH** to confirm. This will complete the editing, save and return to the **RECIPE** screen.

20.2 Create a new batch or edit a batch

Note: the pump must be stopped to enter **DISPENSE SETTINGS**.

1. Press **MODE** to display the **CHANGE MODE** menu.



2. Using the \wedge \vee keys, scroll to **Dispense** and press **SETTINGS**.



1. Highlight **Batches** and press **SELECT**.



2. Highlight **Add new batch** and press **SELECT** to create a new batch or highlight a batch name and press **SELECT** to edit that batch. The **EDIT BATCH** screen is displayed.



3. Press **SELECT** to edit a parameter. Set each parameter to the desired value. See "Batch parameters" on page 108 for a description of the parameters.



4. Enter a batch name:
- Using the \wedge/\vee keys, enter a character.
 - Press **NEXT** to confirm your character and to move onto the next. Press **PREVIOUS** to move the cursor back one character.
 - Move the cursor to the end or beginning of the entry field using **NEXT** or **PREVIOUS**. When the cursor is at the beginning or end of the entry field, press **FINISH** to store the entry.



5. Use the \wedge/\vee keys to highlight **Active Recipe** and press **SELECT**

6. Use the \wedge / \vee keys to highlight the desired recipe and press **SELECT**



7. If you have created a new batch highlight **Save** and press **SELECT**.
8. If you have edited an existing batch highlight **Save** and press **SELECT** to overwrite or to save as a new batch highlight **Save as** and press **SELECT**.
9. Press **FINISH** to confirm. This will complete the editing, save and return to the **BATCH** screen.

20.3 Set the active batch

Note: the pump must be stopped to enter **DISPENSE SETTINGS**.

1. Press **MODE** to display the **CHANGE MODE** menu.



2. Using the \wedge \vee keys, scroll to **Dispense** and press **SETTINGS**



1. Using the \wedge / \vee keys, scroll to **Active batch** and press **SELECT**



2. Choose the batch from the list of created batches and press **SELECT** to confirm.




20.4 Start dispensing

1. From the **CHANGE MODE** menu, highlight **Dispense** and press **SELECT** to use **Dispense** Mode.



2. The pump will display the **DISPENSE** screen.



DISPENSE screen

1 Target volume.

2 Batch name.

3 Batch Progress Icon: The left hand number is the number of dispenses completed, the right hand number is the batch size.

If **Batch size** set to **Unlimited**, only the number of dispenses completed is shown.

4 Flow rate.

Start



Starts the pump, and the display background changes to grey. If the pump is already running, pressing this has no effect.

Stop



Stops the pump. The display background changes to white. If the pump is not running pressing this has no effect.

Info

Pressing the **INFO** function key will display further information.

End batch

1. Pause the batch
 - i. If a **Batch size** has been entered, the batch will pause automatically when the number of fills completed equals the batch size.
 - ii. If a **Batch size** is unlimited or to end a batch early, press **STOP**. Once the current fill has been completed, the batch will pause.

20.5 Dispense settings

Note: the pump must be stopped to enter **DISPENSE SETTINGS**.

1. Select **MODE**



2. Using the \wedge \vee keys, scroll to **DISPENSE** and press **SETTINGS**

The following are available in dispense mode settings:



Active batch

Batch to be dispensed. Select from a list of created batches. To create a new batch refer to "Create a new batch or edit a batch" on page 100

Batches

A **batch** contains the batch size, active recipe, direction and start and end delay. You must create at least one batch and set it as the active batch before Dispense can start.

Batch parameters

Configure the following parameters:

Batch name

The batch name gives the user a convenient way to identify a batch.

Maximum 12 characters. (A-Z, 0-9).

- Using the \wedge/\vee keys, enter a character.
- Press **NEXT** to confirm your character and to move onto the next. Press **PREVIOUS** to move the cursor back one character.
- Move the cursor to the end or beginning of the entry field using **NEXT** or **PREVIOUS**. When the cursor is at the beginning or end of the entry field, press **FINISH** to store the entry.

Batch size

Enter the number of fills to be completed in the batch.

- Minimum - 1
- Maximum - 999999

Press \wedge/\vee to scroll to less than 1 or above 999999 to select UNLIMITED batch size. The pump will continue to dispense until it is stopped by the user.

Active recipe

The recipe that will be used for this batch.

Direction

The pump may be set up so that the direction of rotor rotation is clockwise or counter-clockwise, whichever is required.

Please note, however, that for some pumpheads the tube life will be greater if the rotor rotates clockwise; and that performance against pressure will be maximised if the rotor rotates counter-clockwise. To achieve pressure in some pumpheads the pump must rotate counter-clockwise.

Start delay (batch)

Sets time delay between start signal and first dispense start of the batch.

Refer to "Dispense time delays diagram" on page 112.

End delay (batch)

Sets time delay at the end of the batch.

Refer to "Dispense time delays diagram" on page 112.

Recipes

A **recipe** contains all the parameters for the required dispense. The active recipe must be selected when editing the batch before the dispense can be started. Therefore you must have at least one recipe to start Dispense.

Recipe parameters

Configure the following parameters:

Recipe name

The recipe name gives the user a convenient way to identify a recipe.

Maximum 12 characters. (A-Z, 0-9).

- Using the \wedge/\vee keys, enter a character.
- Press **NEXT** to confirm your character and to move onto the next. Press **PREVIOUS** to move the cursor back one character.
- Move the cursor to the end or beginning of the entry field using **NEXT** or **PREVIOUS**. When the cursor is at the beginning or end of the entry field, press **FINISH** to store the entry.

Volume

This sets the target dispense amount.

- Minimum = 0.1000 millilitres
- Maximum = 99999.9 millilitres

Speed

Rotor speed.

Table 21 - Maximum pump speed

530En/EnN

220 rpm



Excessive speed may cause splashing or foaming.

Anti-drip

If dripping occurs after the fill has completed, increase anti-drip to create "suck back" by momentarily reversing the direction of pumphead. Anti-drip is measured by the number of reverse steps 0-10. Anti-drip values are whole numbers between 0 and 10 where 10 is one complete reverse revolution of the rotor and 0 is no reverse revolution of the rotor.

When using anti-drip, prime the pump before starting each new batch. This will compensate for the volume of fluid that has been retracted due to anti-drip.

Note: To reduce dripping always use an appropriate filling needle and ensure it is perfectly vertical.

Start delay (Recipe)

Sets time delay between start signal and dose start.

Refer to "Dispense time delays diagram" on page 112.

End delay (Recipe)

Sets time delay between pumphead stop and dose complete signal.

Refer to "Dispense time delays diagram" on page 112.

Start ramp

This will set the rate of acceleration when the pump starts.

Can be set to a value between 1 and 5.

1 is the fastest acceleration, 5 is the slowest.

Note: Start ramp is not included in flow calibration.

Stop ramp

This will set the rate of deceleration when the pump stops.

Can be set to a value between 1 and 5.

1 is the fastest deceleration, 5 is the slowest.

Note: Stop ramp is not included in flow calibration.

Delete a recipe

1. Stop the pump.
2. From the **CHANGE MODE** menu, Using the \wedge / \vee keys, scroll to **Dispense** and press **SETTINGS** for **DISPENSE SETTINGS**.
3. Using the \wedge / \vee keys, scroll to **Recipes** and press **SELECT**.
4. Using the \wedge / \vee keys, scroll to a recipe name and press **SELECT** to edit that recipe. The **EDIT RECIPE** screen is displayed.
5. Using the \wedge / \vee keys, scroll to **Delete recipe** and press **SELECT**.

Note: The pump does not use the recipe name to identify a recipe. The pump uses the numerical position in the list of recipes to identify a recipe. Deleting a recipe may change that numerical position. After deleting a recipe, check your batch to make sure the assigned recipe is correct.

Note: The last remaining recipe cannot be deleted.

Dose adjust

Adjust the recipe volume by ± 50 %. Applies adjustment to any active recipe. Set the value to 100% to use the volume defined in the recipe. Set the value to 150% to use +50% above the volume defined in the recipe. Set the value to 50% to use -50% below the volume defined in the recipe.

Resume interrupted

When on - the pump will resume a dose if interrupted by power cycle or if the user stops the batch. The batch will continue from the point it stopped.

When off - the operator must start dosing again following a power cycle. The batch will restart from the beginning.

20.6 Dispense time delays diagram




Figure 21 - Dispense time delays

| | |
|---|---|
| A | Batch (Note: diagrams shows a batch size of three.) |
| B | Pump is stopped |
| C | Pump is dispensing |
| 1 | Batch start delay ("Start delay (batch)" on page 109) |
| 2 | Recipe start delay ("Start delay (Recipe)" on page 110) |
| 3 | Recipe end delay ("End delay (Recipe)" on page 110) |
| 4 | Batch end delay ("End delay (batch)" on page 109) |

21 Dispense with EtherNet/IP™ control

1. Add a recipe and batch using the HMI on the pump by following the procedure in "Create a new recipe or edit a recipe" on page 96 and "Create a new batch or edit a batch" on page 100
2. Leave the pump in **Dispense** mode and have the correct batch active ("Set the active batch" on page 104)
3. Lock the control of the pump using the PIN function ("PIN protection" on page 45)
4. Start/stop the pump using EtherNet/IP™ control.

22 Sensors

Sensors can be connected to the pump to display the value, warnings and errors on pressure and or flow as selected.

Attached sensors allow the user to configure warning and alarm set points on the pump.

Each pump can support a maximum of one flow sensor and one pressure sensor at the same time.

22.1 Sensor wiring

Make sure the sensor is correctly wired to the pump before proceeding with set up. ("Control wiring" on page 24 or "Input/output connectors" on page 31).




Figure 22 - Sensor wiring




Figure 23 - Sensor wiring

22.2 Setting up the sensors

1. From the **CONTROL SETTINGS** menu, using the \wedge / \vee keys, scroll to **Sensors settings** option and press **SELECT**.



2. Using the \wedge / \vee keys, scroll to **Configure sensors** option and press **SELECT**.



- Using the \wedge / \vee keys, scroll to **Flow** or **Pressure** option and press **SELECT**. This selects the type of sensor to configure.



- A list of supported flow sensor families are displayed. The example in the image above shows supported flow sensors. Using the \wedge / \vee keys, scroll to the desired flow sensor and press **SELECT**.



5. The input that the sensor is attached to needs to be assigned.



6. Using the \wedge / \vee keys, scroll to the desired flow sensor and press **SELECT**.



7. See "EtherNet/IP™ control wiring" on page 22 section for connection specifications.



8. Using the \wedge / \vee keys, scroll to the desired sensor size and press **SELECT**.
9. Using the \wedge / \vee keys, scroll to the desired output unit and press **SELECT**.
10. This choice will alter the units displayed on the home screen.

Set Alarm and Warning level

1. Using the \wedge / \vee keys, scroll to the alarm level to set up and press **SELECT**.



2. Using the \wedge / \vee keys, enter a value and press **SELECT** to store. Each one of these defaults to none, once the user sets a value in the edit screens the alarm/warning will become active.



3. When a warning level is triggered the top or bottom bars will show orange



- When an alarm band is triggered the pump will display the “sensor alarm detected” screen and the pump will stop.



22.3 Start up delay

Sets the delay from the motor starting to the alarms/warnings activating. Start-up delay activates on a motor start (irrelevant of mode, includes **MAX**).

- From the control settings menu, using the \wedge / \vee keys, scroll to **Sensor settings** option and press **SELECT**



- From the control settings menu, using the \wedge / \vee keys, scroll to **Set sensor delay** option and press **SELECT**



- Using the \wedge / \vee keys, set a value and press **SELECT** to store.



22.4 Generic sensors

Generic Sensors allow any sensor with a 4-20 mA output and a linear response to be used on the system. The sensor max flow/pressure ratings are shown in a table at the end of this section.

1. From the control settings menu, using the \wedge/\vee keys, scroll to **Sensors settings** option and press **SELECT**



2. Using the \wedge/\vee keys, scroll to **Configure sensors** option and press **SELECT**



3. Using the \wedge/\vee keys, scroll to **Flow** or **Pressure** option and press **SELECT**. This selects the type of sensor to configure.



4. Using the \wedge/\vee keys, scroll to **Generic flow sensor** or **Generic pressure sensor** option and press **SELECT**.



5. Using the \wedge/\vee keys, scroll to **4-20mA input 1** or **4-20mA input 2** option and press **SELECT**. This depends on which connection the user has connected the sensor to. See "EtherNet/IP™ control wiring" on page 22 section for connection specifications. Only generic sensors which provide a 4-20 mA output are supported.



6. Using the \wedge/\vee keys, select the sensor unit output type and press **SELECT**. Options in table below depending on sensor type selection:



Table 22 - Sensor units

| Flow | Pressure |
|--------|----------|
| ul/min | Bar |
| ml/min | Psi |
| ml/hr | |
| l/min | |
| l/min | |

7. After selecting the sensor unit type the user will progress onto the **GENERIC SENSOR VALUES** screen.



8. Using the \wedge/\vee keys, scroll to **Set 4mA value**



9. Using the \wedge/\vee keys, change the value reported when the sensor input is at 4 mA. Once satisfied with the value press **SELECT**.



10. Using the \wedge/\vee keys, scroll to **Set 20mA value**



11. Using the \wedge/\vee keys, change the value reported when the sensor input is at 20 mA. Once satisfied with the value press **SELECT**.



12. Depending on the sensor and units selected the maximum values that can be set at below

Table 23 - Sensor pressure limits

| Pressure Unit | Minimum | Maximum |
|---------------|---------|---------|
| PSI | -10.0 | 75 |
| Bar | -0.689 | 5.171 |

Table 24 - Sensor flow limits

| Flow Unit | Minimum | Maximum |
|-----------|---------|----------|
| ul/min | 0 | 60000000 |
| ml/min | 0 | 60000 |
| ml/hr | 0 | 900000 |
| l/min | 0 | 60 |
| l/hr | 0 | 900 |

Alarm / warning levels

The Warning / error levels screen will then be shown, refer to "Set Alarm and Warning level" on page 117. The error and warning values will default to the value set at 4 mA and 20 mA. The user should set up warnings and errors to suit their process.

Example

If using a 4-20 mA sensor with a range of 0-10 psi:

- Set the 4 mA to 0 psi
- Set the 20 mA to 10 psi
- The Alarm Max was set at 8 psi
- The Warning Max was set at 7 psi
- The Warning Min was set at 3 psi
- The Alarm Min was set at 2 psi




Figure 24 - Set Alarm / warning levels

A

Current (A) / Pressure (psi)

An alarm event is indicated by the solid lines (A_L , A_H) on the graph. During an alarm event the pump will show the alarm red screen and stop. This alarm is triggered by the sensor signal being equal to or greater than that set by the Alarm Max/Min or Ethernet Hi-Hi/Lo-Lo Parameters. The user has to acknowledge this screen on the pump.

A warning event is indicated by the dashed lines (W_L , W_H) on the graph. During a warning event the pump will show orange sections on the screen and a warning bit will flag on the Ethernet communications. This event is triggered by the sensor signal being equal to or greater than the value set by the Warning Max/Min or Ethernet Hi-Lo/Lo-Hi Parameters.

Note: It is normal to expect fluctuations in both pressure and flow systems using peristaltic pumps. This means that warning and alarm limits need to take short term spikes and changes into account when setting these limits.

Note: The pump has no control over the accuracy of the signals coming from the sensors and will simply respond to the signal levels received. Sensor accuracy is the responsibility of the sensor supplier and will be dependent on a range of system variables, for example fluid type, tube material and temperature.

Procedure

1. From the **GENERIC SENSOR VALUES** screen.



2. Using the \wedge/\vee keys, scroll to **Alarm / warning levels**



- Using the \wedge/\vee keys, select the value to change and press **SELECT**.



- Using the \wedge/\vee keys, scroll to the desired value and press **SELECT**
- Press **BACK** to store the changes and return to the **GENERIC SENSOR VALUES** screen

Scaling factor for generic sensors

Set slope adjust

The slope parameter will scale the slope of the channel as defined by the 4mA and the 20mA points. The parameter can take a value from 0.8 to 1.2 where 1 will result in no change to the slope.




Figure 25 - Set slope adjust

A Sensor configuration determined by the 4mA value and 20mA value

B Set slope adjust is greater than 1

C Set slope adjust is less than 1

y_1 4mA value ("Generic sensors" on page 120)

y_2 20mA value ("Generic sensors" on page 120)

Procedure

1. From the **GENERIC SENSOR VALUES** screen.



2. Using the \wedge / \vee keys, scroll to **Set slope adjust**



3. Using the \wedge / \vee keys, scroll to the desired value and press **SELECT**



Set offset adjust

The offset parameter will apply an offset across the mA range of the channel and not affect the slope.




Figure 26 - Set offset adjust

A Sensor configuration determined by the 4mA value and 20mA value

B Set offset adjust is greater than 1

C Set offset adjust is less than 1

y_1 4mA value

y_2 20mA value

Procedure

1. From the **GENERIC SENSOR VALUES** screen.



2. Using the \wedge / \vee keys, scroll to **Set offset adjust**



- Using the \uparrow/\downarrow keys, scroll to the desired value and press **SELECT**



22.5 Flow sensor reading

- The flow sensor value can be read via the Flow sensor reading screen



23 Troubleshooting

If the pump display remains blank when the pump is switched on, make the following checks:

- Check that the mains power is available to the pump.
- Check the fuse in the wall plug if one is present.
- Check the position of the voltage selector switch.
- Check the mains power switch at the rear of the pump.
- Check the fuse in the fuse holder in the centre of the switch plate at the rear of the pump.

If the pump runs but there is little or no flow, make the following checks:

- Check that fluid is supplied to the pump.
- Check for any kinks or blockages in the lines.
- Check that any valves in the line are open.
- Check that the tube and rotor are in the pumphead.
- Check that the tube is not split or burst.
- Check that the correct wall-thickness tube is being used.
- Check the direction of rotation.
- Check that the rotor is not slipping on the drive shaft.

If the pump turns on, but will not run:

- Check the remote stop function and configuration.
- Check the mode you are in, are you in **Analog** mode.
- Try to operate and run the pump in **Manual** mode.

23.1 Error codes

If an internal error occurs, an error screen with a red background is displayed. Note: Signal out of range, over signal and leak detected error screens report the nature of an external condition. They do not flash.

Table 25 - Error codes

| Error code | Error condition | Suggested action |
|------------|---------------------------------------|---|
| Er 0 | FRAM write error | Attempt to reset by switching power OFF/ON. Or seek support. |
| Er 1 | FRAM corruption | Attempt to reset by switching power OFF/ON. Or seek support. |
| Er 2 | FLASH write error during drive update | Attempt to reset by switching power OFF/ON. Or seek support. |
| Er 3 | FLASH corruption | Attempt to reset by switching power OFF/ON. Or seek support. |
| Er 4 | FRAM shadow error | Attempt to reset by switching power OFF/ON. Or seek support. |

Table 25 - Error codes

| Error code | Error condition | Suggested action |
|-------------------|--|---|
| Er 9 | Motor stalled | Stop pump immediately. Check pumphead and tube. Power OFF/ON may reset. Or seek support. |
| Er10 | Tacho fault | Stop pump immediately. Power OFF/ON may reset. Or seek support. |
| Er14 | Speed error | Stop pump immediately. Power OFF/ON may reset. Or seek support. |
| Er15 | Over current | Stop pump immediately. Power OFF/ON may reset. Or seek support. |
| Er16 | Over voltage | Stop pump immediately. Check supply. Power OFF/ON may reset. |
| Er17 | Under voltage | Stop pump immediately. Check supply. Power OFF/ON may reset. |
| Er20 | Signal out of range | Check analog control signal range. Trim signal as required. Or seek support. |
| Er21 | Over signal | Reduce the analog control signal. |
| Err50 | Communication error (internal pump communications error and not a network error) | Attempt to reset by switching power OFF/ON. Or seek support. |

23.2 Technical support

Watson-Marlow Fluid Technology Group
Falmouth, Cornwall
TR11 4RU
UK

Contact your local Watson-Marlow representative for support.
www.wmftg.com/contact

24 Drive maintenance

There are no user serviceable parts inside the pump. Please contact your local Watson-Marlow representative to arrange repair.

25 Drive spares

Table 26 - Drive spares

| Description | Part No. |
|--|--------------|
| Replaceable main fuse, type T2, 2.5A H 250 V 20 mm (Pack of 5) | MNA2107A |
| Foot (Pack of 5) | MNA2101A |
| Module seal | MN2516B |
| Module switch cover | MN2505M |
| Glands (STD) | GR0056 |
| Glands (EMC) | GR0075 |
| Blanking plugs | GR0057 |
| Sealing washer for blanking plug and gland | GR0058 |
| Snap-fit vent | MN2513B |
| M12 cover | MN2943B |
| M12 collars insulated | MN2934T |
| M12 collars non insulated | MN2935T |
| Ethernet Cable, M12D Right Angle 4 pin plug to M12D Straight 4 pin plug, CAT 5 SHIELDED, 3 m | 059.9121.000 |
| Ethernet Cable, M12D Right Angle 4 pin plug to RJ45, CAT 5 SHIELDED, 3 m | 059.9122.000 |
| Ethernet Cable, RJ45 to RJ45, CAT 5e SHIELDED, 3 m | 059.9123.000 |
| RJ45(skt) TO M12 D CODE (skt) ADAPTER IP68 | 059.9124.000 |
| Leak Detector Kit for 530 En | 059.9151.000 |
| Leak Detector Kit for 530 EnN | 059.9161.000 |
| RJ45 to RJ45 Patch Cable (NEMA module internal) | 059.9125.000 |

26 Pumphead replacement




Always isolate the pump from the mains power supply before opening any guard or track, or performing any positioning, removal or maintenance operation.



Primary safety is provided by the tool-lockable pumphead track. Secondary (backup) protection is provided in the form of an optional guard switch which stops the pump if the pumphead track is opened. The optional guard switch on cased pumps should never be used as primary protection. Always disconnect the mains power supply to the pump before opening the pumphead guard.

26.1 520R pumphead replacement




27 Tube replacement




Always isolate the pump from the mains power supply before opening any guard or track, or performing any positioning, removal or maintenance operation.

27.1 Continuous tubing

520R and 520R2



505L



$\leq 8.0 \text{ mm} = 145 \text{ mm}$,
 $9.6 \text{ mm} = 150 \text{ mm}$

27.2 Tube elements

| Grey | Beige | Blue |
|---|---|---|
| Up to 2 bar (30 psi) | Up to 4 bar (60 psi) | Up to 7 bar (100 psi) |
|  |  |  |

Purple

(Maxthane tubing)


3.2 mm - Up to 7 bar (100 psi)

6.4 mm - Up to 4 bar (60 psi)

9.6 mm - Up to 2 bar (30 psi)



520REL, 520REM, 520REH and 520RET



530 Sanitary connectors



530 Industrial connectors



1.



2.



3.

505L



1.



2.



3.




4.

Table 27 - General guide to cleaning with solvents

| Chemical | Cleaning precautions |
|----------------------------------|---|
| Aliphatic hydrocarbons | Remove guard. Minimize rotor cap and clutch boot exposure to less than one minute (risk of attack). |
| Aromatic hydrocarbons | Remove guard. Minimize rotor cap and clutch boot exposure to less than one minute (risk of attack). |
| Ketone solvents | Remove guard. Minimize rotor cap and clutch boot exposure to less than one minute (risk of attack). |
| Halogenated/chlorinated solvents | Not recommended: possible risk to polycarbonate tube clamp adjusters and polypropylene tube clamp locators. |
| Alcohols, general | No precaution necessary. |
| Glycols | Minimize rotor cap and clutch boot exposure to less than one minute (risk of attack). |
| Estersolvents | Remove guard. Minimize rotor cap and tube clamp location cap exposure to less than one minute (risk of attack). |
| Ether solvents | Not recommended: possible risk to polycarbonate tube clamp adjusters and polypropylene tube clamp locators. |

28 Ordering information

28.1 Pump part numbers



Special NEMA module 059.911F.100 Ethernet Watertight Module (530F) IP66 NEMA 4X is required for KROHNE flow sensor, combined with IP31 pump

28.2 Tubing and element part numbers

Table 28 - 1.6 mm wall tubing for 520R pumpheads



| mm | inch | # | Marprene | Bioprene | STA-PURE Series PFL |
|-----|------|-----|---------------------|--------------|---------------------|
| 0.5 | 1/50 | 112 | 902.0005.016 | 933.0005.016 | — |
| 0.8 | 1/32 | 13 | 902.0008.016 | 933.0008.016 | — |
| 1.6 | 1/16 | 14 | 902.0016.016 | 933.0016.016 | 966.0016.016 |
| 3.2 | 1/8 | 16 | 902.0032.016 | 933.0032.016 | 966.0032.016 |
| 4.8 | 3/16 | 25 | 902.0048.016 | 933.0048.016 | 966.0048.016 |
| 6.4 | 1/4 | 17 | 902.0064.016 | 933.0064.016 | 966.0064.016 |
| 8.0 | 5/16 | 18 | 902.0080.016 | 933.0080.016 | 966.0080.016 |
| mm | inch | # | STA-PURE Series PCS | Neoprene | |
| 0.8 | 1/32 | 13 | — | 920.0008.016 | |
| 1.6 | 1/16 | 14 | — | 920.0016.016 | |
| 3.2 | 1/8 | 16 | 961.0016.016 | 920.0032.016 | |
| 4.8 | 3/16 | 25 | 961.0032.016 | 920.0048.016 | |
| 6.4 | 1/4 | 17 | 961.0048.016 | 920.0064.016 | |
| 8.0 | 5/16 | 18 | 961.0064.016 | 920.0080.016 | |
| mm | inch | # | Pumpsil | | |
| 0.5 | 1/50 | 112 | 913.A005.016 | | |
| 0.8 | 1/32 | 13 | 913.A008.016 | | |
| 1.6 | 1/16 | 14 | 913.A016.016 | | |
| 3.2 | 1/8 | 16 | 913.A032.016 | | |
| 4.8 | 3/16 | 25 | 913.A048.016 | | |
| 6.4 | 1/4 | 17 | 913.A064.016 | | |
| 8.0 | 5/16 | 18 | 913.A080.016 | | |

Note: 1.6 mm wall STA-PURE Series PFL and STA-PURE Series PCS tubing are supplied in 305 mm lengths.

Table 29 - 2.4 mm wall tubing for 520R2 pumpheads

| mm | inch | # | Marprene | Bioprene | Pumpsil |
|-----|------|-----|---------------------|---------------------|--------------|
| 0.5 | 1/50 | — | — | — | 913.A005.024 |
| 0.8 | 1/32 | — | — | — | 913.A008.024 |
| 1.6 | 1/16 | 119 | 902.0016.024 | 933.0016.024 | 913.A016.024 |
| 3.2 | 1/8 | 120 | 902.0032.024 | 933.0032.024 | 913.A032.024 |
| 4.8 | 3/16 | 15 | 902.0048.024 | 933.0048.024 | 913.A048.024 |
| 6.4 | 1/4 | 24 | 902.0064.024 | 933.0064.024 | 913.A064.024 |
| 8.0 | 5/16 | 121 | 902.0080.024 | 933.0080.024 | 913.A080.024 |
| 9.6 | 3/8 | 122 | 902.0096.024 | 933.0096.024 | 913.A096.024 |
| mm | inch | # | STA-PURE Series PFL | STA-PURE Series PCS | |
| 0.8 | 1/32 | — | — | — | |
| 1.6 | 1/16 | 119 | 966.0016.024 | 961.0016.024 | |
| 3.2 | 1/8 | 120 | 966.0032.024 | 961.0032.024 | |
| 4.8 | 3/16 | 15 | 966.0048.024 | 961.0048.024 | |
| 6.4 | 1/4 | 24 | 966.0064.024 | 961.0064.024 | |
| 8.0 | 5/16 | 121 | 966.0080.024 | 961.0080.024 | |

Note: 2.4 mm wall STA-PURE Series PFL and STA-PURE Series PCS tubing are supplied in 355 mm lengths.

Table 30 - 2.4 mm wall elements for 520RE pumpheads**0-2 bar (0-30 psi) pressure rated elements****Industrial**

| mm | inch | # | Marprene TL | Pumpsil | Neoprene |
|-----|------|-----|--------------|--------------|--------------|
| 3.2 | 1/8 | 16 | 902.0032.PFQ | 913.A032.PFQ | 920.0032.PFQ |
| 6.4 | 1/4 | 17 | 902.0064.PFQ | 913.A064.PFQ | 920.0064.PFQ |
| 9.6 | 3/8 | 122 | 902.0096.PFQ | 913.A096.PFQ | 920.0096.PFQ |

Table 30 - 2.4 mm wall elements for 520RE pumpheads

0-2 bar (0-30 psi) pressure rated elements



Industrial

Sanitary

| mm | inch | # | Bioprene TL | Pumpsil | STA-PURE Series PCS | STA-PURE Series PFL |
|-----|------|-----|--------------|--------------|---------------------|---------------------|
| 3.2 | 1/8 | 16 | 933.0032.PFT | 913.A032.PFT | 961.0032.PFT | 966.0032.PFT |
| 6.4 | 1/4 | 17 | 933.0064.PFT | 913.A064.PFT | 961.0064.PFT | 966.0064.PFT |
| 9.6 | 3/8 | 122 | 933.0096.PFT | 913.A096.PFT | 961.0096.PFT | 966.0096.PFT |

Table 31 - 2.4 mm wall elements for 520RE pumpheads

2-4 bar (30-60 psi) pressure rated elements



Industrial

| mm | inch | # | Marprene TM |
|-----|------|----|--------------|
| 3.2 | 1/8 | 16 | 902.P032.PFQ |
| 6.4 | 1/4 | 17 | 902.P064.PFQ |

Sanitary

| mm | inch | # | Bioprene TM | STA-PURE Series PCS |
|-----|------|----|--------------|---------------------|
| 3.2 | 1/8 | 16 | 933.P032.PFT | 961.M032.PFT |
| 6.4 | 1/4 | 17 | 933.P064.PFT | 961.M064.PFT |

Table 32 - 2.4 mm wall elements for 520RE pumpheads

Table 33 - 4-7 bar (60-100 psi) pressure rated elements



Industrial

| mm | inch | # | Marprene TH |
|-----|------|----|--------------|
| 3.2 | 1/8 | 16 | 902.H032.PFQ |

Sanitary

| mm | inch | # | Bioprene TH | STA-PURE Series PCS |
|-----|------|----|--------------|---------------------|
| 3.2 | 1/8 | 16 | 933.H032.PFT | 961.H032.PFT |

Table 34 - 1.6 mm wall elements for 520RET pumpheads

0-2 bar (0-30 psi) pressure rated elements



Sanitary

| mm | inch | # | Maxthane |
|-----|------|-----|--------------|
| 9.6 | 3/8 | 122 | 945.0096.PFT |

Table 35 - 1.6 mm wall elements for 520RET pumpheads

0-4 bar (0-60 psi) pressure rated elements



Sanitary

| mm | inch | # | Maxthane |
|-----|------|----|--------------|
| 6.4 | 1/4 | 17 | 945.0064.PFT |

Table 36 - 1.6 mm wall elements for 520RET pumpheads


0-7 bar (0-100 psi) pressure rated elements



Sanitary

| mm | inch | # | Maxthane |
|-----|------|----|--------------|
| 3.2 | 1/8 | 16 | 945.0032.PFT |

28.3 Pumphead spares



520R/520R2

520REL/520REM/520REH

Table 37 - Pumphead spares

| Assembly number | Part Number | Description |
|-------------------|-------------------------------------|---|
| Complete pumphead | 053.1011.100 | 520R |
| | 053.1011.2L0 | 520R2 |
| | 053.1011.EL0 | 520REL |
| | 053.1011.EM0 | 520REM |
| | 053.1011.EH0 | 520REH |
| | 053.1011.ET0 | 520RET |
| 1 | MNA2050A (520R, 520R2) | Pumphead guard complete with tool-unlockable latch |
| 2 | MNA2045A (520R, 520R2) | Track assembly for cased pumps complete with spring-loaded tube clamps |
| 3 | MNA2043A (520R - 1.6 mm wall tube) | Rotor assembly complete with pumping rollers, follower rollers and tube guide rollers |
| | MNA2001A (520R2 - 2.4 mm wall tube) | |
| | MNA2138A (grey) (520REL) | |
| | MNA2139A (beige) (520REM) | |
| | MNA2140A (blue) (520REH) | |
| | MNA2456A (purple) (520RET) | |

Table 37 - Pumphead spares

| Assembly number | Part Number | Description |
|------------------------|-----------------------------|--|
| 4 | MNA2006A (520R, 520R2) | Bottom (LH) tube clamp Tube clamp location plug Drain plug |
| | MN2002M (520R, 520R2) | |
| | MN2131M (520RE) | |
| 5 | MNA2005A (520R, 520R2) | Top (RH) tube clamp |
| | MN2002M (520R, 520R2) | Tube clamp location plug |
| 6 | MN2034B | Guard latch spring |
| | MN2005M | Guard latch spring cartridge |
| 7 | MNA2147A (520RE) | Pumphead guard complete with seal and tool-lockable latch |
| 8 | MNA2144A (520RE) | Track assembly for cased pumps |
| 9 | MN2023T and MN2003T (520RE) | Drain port and nut |

29 Performance data

29.1 Performance curves

Flow rates of suction and discharge pressures for the pumphead at different drive speeds. This data was produced pumping water at ambient temperature.

Figure 27 - Marprene continuous tubing, 1.6 mm wall, 200 rpm, clockwise rotation




Figure 28 - Marprene continuous tubing, 1.6 mm wall, 200 rpm, counter-clockwise rotation




Figure 29 - Marprene continuous tubing, 2.4 mm wall, 200 rpm, clockwise rotation




Figure 30 - Marprene continuous tubing, 2.4 mm wall, 200 rpm, counter-clockwise rotation




Figure 31 - Marprene TL element, 0-2 bar (0-30 psi), 200 rpm, counter-clockwise rotation




Figure 32 - Sta-Pure element, 0-2 bar (0-30 psi), 200 rpm, counter-clockwise rotation




Figure 33 - Marprene TM element, 2-4 bar (20-60 psi), 200 rpm, counter-clockwise rotation




Figure 34 - Sta-Pure element, 2-4 bar (30-60 psi), 200 rpm, counter-clockwise rotation




Figure 35 - Marprene TH element, 4-7 bar(60-100 psi), 200 rpm, counter-clockwise rotation





Figure 36 - Maxthane LoadSure Elements, Counter clockwise Rotation 200 rpm RET rotor



Note: To achieve the discharge pressures stated above, the rotor must be run counter clockwise. To achieve optimal tube life, run the rotor clockwise at a maximum discharge pressure of 2 bar.

30 Trademarks

Watson- Marlow, LoadSure, Qdos, ReNu, LaserTraceability, Pumpsil, PureWeld XL, Bioprene, Marprene, Maxthane are registered trademarks of Watson-Marlow Limited. Tri-Clamp is a registered trademark of Alfa Laval Corporate AB.

STA-PURE Series PCS and STA-PURE Series PFL are trademarks of W.L.Gore and Associates.

EtherNet/IP™ is a trademark of ODVA, Inc.

Studio 5000® is a trademark of Rockwell Automation.

Siemens is a registered trademark of Siemens AG.

SciLog® and SciPres® are registered trademarks of Parker Hannifin Corporation.

BioProTT™ is a trademark of em-tec GmbH.

PendoTECH® and PressureMAT® are registered trademarks of PendoTECH

FLEXMAG™ is a trademark of KROHNE Messtechnik GmbH

SONOFLOW® is a trademark and brand of SONOTEC Ultraschallsensorik Halle GmbH.

31 Disclaimers

The information contained in this document is believed to be correct but Watson-Marlow Fluid Technology Group accepts no liability for any errors it contains and reserves the right to alter specifications without notice.

WARNING: This product is not designed for use in and should not be used for, patient-connected applications.

32 Publication history

| File | Date of issue | Notes |
|---------------------------------|---------------|---|
| m-530en-en-01 530 En/EnN pump | 06.20 | First release |
| m-530en-en-08 530 En/EnN pump | 07.20 | All versions updated and unified to Issue 8 |
| m-530en-en-08.1 530 En/EnN pump | 01.21 | Updated EtherNet/IP™ EDS information. Maxthane® tubing data added. |
| m-530en-en-09 530 En/EnN pump | 01.22 | Updated EtherNet/IP™ EDS information. Added dispense section. Added sensor scaling. |

33 List of tables and figures

33.1 Tables

| | |
|---|-----|
| Table 1 - Specification ratings | 12 |
| Table 2 - Weights | 13 |
| Table 3 - Conductor colour coding | 19 |
| Table 4 - Wiring the D-Connector | 25 |
| Table 5 - Input/output Connectors | 31 |
| Table 6 - External interface parameters | 33 |
| Table 7 - Allowance for one additional connection pair | 36 |
| Table 8 - First-time start-up defaults | 39 |
| Table 9 - Configure EtherNet/IP™ settings | 77 |
| Table 10 - Cyclic parameters | 82 |
| Table 11 - Acyclic Parameters | 87 |
| Table 12 - PumpModel | 89 |
| Table 13 - PumpHead | 90 |
| Table 14 - Wallsize | 91 |
| Table 15 - BoreSize | 92 |
| Table 16 - PressureSensorModel | 93 |
| Table 17 - PressureSensorSize | 93 |
| Table 18 - FlowSensorModel | 94 |
| Table 19 - FlowSensorSize | 94 |
| Table 20 - EDS compatibility guide | 94 |
| Table 21 - Maximum pump speed | 110 |
| Table 22 - Sensor units | 124 |
| Table 23 - Sensor pressure limits | 126 |
| Table 24 - Sensor flow limits | 126 |
| Table 25 - Error codes | 135 |
| Table 26 - Drive spares | 138 |
| Table 27 - General guide to cleaning with solvents | 142 |
| Table 28 - 1.6 mm wall tubing for 520R pumpheads | 144 |
| Table 29 - 2.4 mm wall tubing for 520R2 pumpheads | 145 |
| Table 30 - 2.4 mm wall elements for 520RE pumpheads | 145 |
| Table 31 - 2.4 mm wall elements for 520RE pumpheads | 146 |
| Table 32 - 2.4 mm wall elements for 520RE pumpheads | 147 |
| Table 33 - 4-7 bar (60-100 psi) pressure rated elements | 147 |
| Table 34 - 1.6 mm wall elements for 520RET pumpheads | 147 |
| Table 35 - 1.6 mm wall elements for 520RET pumpheads | 147 |
| Table 36 - 1.6 mm wall elements for 520RET pumpheads | 147 |
| Table 37 - Pumphead spares | 148 |

33.2 Figures

| | |
|--|-----|
| Figure 1 - 530 pump range | 13 |
| Figure 2 - Pump stacking | 14 |
| Figure 3 - Rotor direction | 14 |
| Figure 4 - Keypad layout and key IDs | 16 |
| Figure 5 - Starting and stopping | 17 |
| Figure 6 - Using up and down keys | 17 |
| Figure 7 - Maximum speed | 17 |
| Figure 8 - Change rotation direction | 17 |
| Figure 9 - Voltage selector | 18 |
| Figure 10 - Earth screening of control cables on EtherNet/IP™ NEMA module | 19 |
| Figure 11 - M12 connector screen connection | 21 |
| Figure 12 - RJ45 connections | 24 |
| Figure 13 - Wiring the 9 way D sensor connector | 24 |
| Figure 14 - N Module and F Module | 28 |
| Figure 15 - Ethernet connection | 29 |
| Figure 16 - Adapter PCB | 29 |
| Figure 17 - Power supply options | 30 |
| Figure 18 - Star network | 34 |
| Figure 19 - Ring network | 35 |
| Figure 20 - Line topology | 35 |
| Figure 21 - Dispense time delays | 112 |
| Figure 22 - Sensor wiring | 113 |
| Figure 23 - Sensor wiring | 113 |
| Figure 24 - Set Alarm / warning levels | 127 |
| Figure 25 - Set slope adjust | 130 |
| Figure 26 - Set offset adjust | 132 |
| Figure 27 - Marprene continuous tubing, 1.6 mm wall, 200 rpm, clockwise rotation | 150 |
| Figure 28 - Marprene continuous tubing, 1.6 mm wall, 200 rpm, counter-clockwise rotation .. | 150 |
| Figure 29 - Marprene continuous tubing, 2.4 mm wall, 200 rpm, clockwise rotation | 151 |
| Figure 30 - Marprene continuous tubing, 2.4 mm wall, 200 rpm, counter-clockwise rotation .. | 151 |
| Figure 31 - Marprene TL element, 0-2 bar (0-30 psi), 200 rpm, counter-clockwise rotation | 152 |
| Figure 32 - Sta-Pure element, 0-2 bar (0-30 psi), 200 rpm, counter-clockwise rotation | 152 |
| Figure 33 - Marprene TM element, 2-4 bar (20-60 psi), 200 rpm, counter-clockwise rotation .. | 153 |
| Figure 34 - Sta-Pure element, 2-4 bar (30-60 psi), 200 rpm, counter-clockwise rotation | 153 |
| Figure 35 - Marprene TH element, 4-7 bar(60-100 psi), 200 rpm, counter-clockwise rotation .. | 154 |
| Figure 36 - Maxthane LoadSure Elements, Counter clockwise Rotation 200 rpm RET rotor | 154 |